

PORODO
LIFESTYLE



Porodo Lifestyle

**AquaSplash
Electric Garden Sprayer**

SKU:PDLFSTEWPOG

Table of Contents

Product Overview	2
Safety Instructions	2
Important Tips	2
Specifications	3
Operation & Charging	3
Schematic View	4
Instructions for Use	4
Disposal	5
Warranty	5
Contact Us	5

Product Overview

The AquaSplash Electric Garden Sprayer features an 8-liter water tank and dual spray options, making it perfect for various gardening tasks. Equipped with three multi-shape nozzles, it provides versatile spraying patterns. The sprayer includes an LED charging indicator and uses Type-C charging for quick and efficient power. Its multi-function design ensures a smooth and effective gardening experience, making it ideal for watering, fertilizing, or applying pesticides.

Safety Instructions

- 1.** Do not disassemble or modify the product.
- 2.** Ensure that the charger's output voltage and current meet the product's specifications.
- 3.** Do not immerse the product in water.
- 4.** Do not spray with thick or corrosive liquids.
- 5.** Do not direct the sprayer towards high temperatures.
- 6.** Do not use the sprayer while charging.
- 7.** Ensure that the sprayer contains liquid before use.

Important Tips

- 1.** Please recharge the batteries before use.
- 2.** After use, ensure there is no remaining liquid in the sprayer and clean it with water.
- 3.** To extend battery life, it is recommended to charge the product every two months when not in use.

Specifications

Material	ABS/HDPE
Input	5V/2A
Battery Capacity	1500mAh
Charging Port	Type-C
Nozzles	3 Nozzles (Cone, Fan-Shape, Five-Hole)
Water Tank Capacity	8L
Water Pressure	0.3MPa
Product Size	105 × 320 × 330mm
Model	PDLFSTEWPOG

Operation & Charging

A. Powering On/Off

1. Press the button briefly to turn on the device. The blue light will illuminate to indicate the device is operating.
2. Press the button again to turn off the device. The blue light will go out when the device is off.


B. Charging Indicator

1. Connect the charger to the device. The red light will turn on to indicate the device is charging.
2. When the device is fully charged, the red light will turn off.

C. Simultaneous Charging and Use

The device allows for use while it is charging. You can operate the device without interruption even when connected to a charger.

Schematic View



Instructions for Use

1. Attach the nozzle to the telescopic rod, and then attach the telescopic rod to the electric handle.
2. Install the strap and handle lid on the water tank. Place the sealing gasket on the suction pipe sleeve and insert it into the water tank's threaded opening.
3. Connect the two ends of the connecting nut. Attach the water tank connection nut and the electric handle connection nut. Then, connect the water pipe to both the suction pipe and the electric handle, and tighten the nuts securely.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.porodo.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: <https://www.porodo.net/>

Service Support: support@porodo.net

Instagram: [porodo](#)