

**PORODO**  
LIFESTYLE



**Porodo Lifestyle**  
**JETBLAZE**  
**WINDPROOF FLAME LIGHTER**

SKU: PDLFSTWBGLBK

# Table of Contents

Product Overview	2
Specifications	2
Filling the Gas Cartridge	3
Lighting the Torch	3
Storage	4
Safety Precautions	4
Disposal	5
Warranty	5
Contact Us	5

## Product Overview

The JetBlaze Windproof Flame Lighter by Porodo Lifestyle is a high-performance tool designed for those seeking precision and reliability in their lighting needs. With an adjustable flame and turbo flame intensity reaching up to 1350°C, it offers a powerful and focused flame that works in various conditions, including windy environments. The lighter features a safety lock for secure handling and is designed for easy refilling with a gas cartridge, ensuring prolonged use. Whether for professional or personal use, this lighter combines durability and efficiency in a compact design.

## Specifications

Material	Zinc Alloy, Aluminum, Polyformaldehyde
Flame Type	Turbo Flame
Temperature	2500°F / 1350C
Fuel Type	Butane & Propane Mixture
Product Size	4.5 x 7.8 x 13.6cm
Product Weight	211.2g
Model Number	PDLFSTWBGL

## **Filling the Gas Cartridge**

1. Use only high-quality butane gas refills, available at most retail locations. The burner is supplied without a gas cylinder.
2. Always refill in a well-ventilated area.
3. Do not press the power button while refilling.
4. Shake the gas canister to warm the fuel.
5. Insert the gas container stem vertically into the refill valve at the bottom of the lighter. Press firmly for about 3 seconds. Repeat 3-4 times for maximum refueling.
6. Wait 2 minutes before igniting the lighter.
7. Clean the burner and your hands after refilling.
8. Never refill near an open flame. The lighter contains flammable gas under pressure after refilling.

## **Lighting the Torch**

1. Press the ignition button to ignite the flame.
2. Adjust the flame size by turning the flame control: tilt towards (+) to increase the flame or (-) to decrease. Avoid over-increasing the flame, as it may cause instability.
3. For continuous burning, set the flame control to the "lock" position.
4. Press the power button, then turn the "lock" to the right, following the arrow direction, for continuous combustion. To stop the flame, press the "lock" in the opposite direction of the arrow.
5. Limit the burning interval to 2 minutes. After each ignition, wait at least 1 minute before reigniting to prevent overheating and potential damage to the plastic parts.

## Storage

Always set the safety lock to the "Lock" position to prevent accidental ignition when the torch is not in use. After use, allow the device to cool completely before storing it in a dry place, away from children.

## Safety Precautions

1. Keep out of the reach of children.
2. Butane gas is highly flammable. Use with care. Contains flammable gas under pressure.
3. Never direct the flame towards your face or clothing. The flame may be difficult to see, so exercise caution.
4. Do not touch the flame nozzle during or after use with your hand or any other combustible material until the nozzle is cool.
5. Do not keep the power on for more than 30 seconds.
6. Always allow the burner to cool completely before storing.
7. Never expose the burner to temperatures above 40°C (104°F) or prolonged sunlight.
8. The burner may not ignite if the temperature is too cold or if oxygen levels are low.
9. Do not pierce the burner or throw it into the fire. Avoid disassembling the burner yourself.
10. Ensure the flame is fully extinguished after use.
11. There is extreme heat above the visible flame. Take extra care to avoid burns or injuries.
12. Do not use the burner to light cigarettes, cigars, or pipes.

## **Disposal**

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.porodo.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
<https://www.porodo.net/warranty>

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:  
[info@porodo.net](mailto:info@porodo.net)  
Website: <https://www.porodo.net/>  
Service Support: [support@porodo.net](mailto:support@porodo.net)  
Instagram: **porodo**