

# PORODO



## Porodo

**2-In-1  
Air Duster & Vacuum Cleaner**

SKU: PDVC50BK



# Table of Contents

Product Overview	2
Specifications	2
Schematic View	3
Package Contents	4
Product Modes	4
Instructions for use	7
Care and Maintenance	8
Safety Precautions	8
FCC Statement	9
Disposal	10
Warranty	11
Contact Us	11

## Product Overview

The Porodo 2-in-1 Air Duster and Vacuum Cleaner is a powerful cleaning tool designed for efficient dust removal and air blowing. With a motor reaching up to 130,000 RPM and eight adjustable speed levels, it includes multiple nozzles for versatile cleaning. The LED display shows the current settings, and the Type-C charging port ensures fast recharging. Offering up to 5 hours of usage on a single charge, this device is perfect for both home and professional use, ensuring dust-free precision.

## Specifications

Material	Plastic
Input	5V/3A
Rated Power	150W
Battery Capacity	4000mAh x2
Working Time	15-300 min
Recharge Time	4h
Motor Speed	26,000-130,000 RPM
Suction Power	2.5-7.5 Kpa

Cable Length	60 cm
Charging Interface	USB-C
Product Size	30 x 76 × 142 mm
Product Weight	268g (without nozzles), 361g (with nozzles)
Model Number	PDVC50

## Schematic View






## Package Contents



- 1. VC50 Turbo Fan ×1
- 2. Long Blow Nozzle ×1
- 3. Short Blow Nozzle ×1
- 4. Type-C Charging Cable ×1
- 5. Washable Dust Filter ×1
- 6. Vacuum Nozzle with Brush ×1
- 7. Vacuum Cup ×1

## Product Modes

- 1. Air Duster Mode




- 1.1. Attach the appropriate nozzle by twisting it onto the device.
- 1.2. Press and hold the Power button for about one second to turn the device on.
- 1.3. Push the Control button upwards to select from eight distinct speed levels.

#### Notes:

- a. The handle may become warm during use due to heat from the battery.
- b. The temperature of the handle may reach up to 45°C, which is normal and within the safe operating range.

2. Vacuum Cleaner Mode



- 2.1.** Attach the appropriate nozzle by twisting it onto the device.
- 2.2.** Press and hold the Power button for about one second to activate the device.
- 2.3.** Push the Control button upwards to select from eight distinct speed levels.

### **Notes:**

- a.** To clean the dust filter, remove it from the device as shown in the image.
- b.** Rinse the filter under water and allow it to dry before reattaching it to the device.

## **Instructions for use**

### **1. Operation and Speed Adjustment**

- 1.1.** Press and hold the Power button to turn the product on.
- 1.2.** The fan will start at the 1st gear by default.
- 1.3.** Push the Control button upwards to increase the wind speed through eight distinct levels.
- 1.4.** Each speed increment represents a gradual increase in wind force.
- 1.5.** Push the Control button downwards to decrease the wind speed.
- 1.6.** The fan will gradually reduce the speed until turned off.
- 1.7.** The gear shift indicator will display the current speed setting, ranging from soft to super violent wind.

### **2. Charging**

- 2.1.** The product supports fast charging chargers.
- 2.2.** Charging is not allowed during use.

### **3. Battery Indicator Light**

- 3.1.** A green charging indicator ( ⚡ ) flashes on the display when charging.
- 3.2.** The green charging indicator stops flashing when fully charged.
- 3.3.** In low power state, the screen will flash 00% and shut down.



## Care and Maintenance

- 1.** Store the product out of reach of children and pets.
- 2.** Keep the product in a dry environment. Avoid placing it in high temperatures or in direct sunlight, such as in a car.
- 3.** Regularly remove any debris, hair, or dust from the air intake area.
- 4.** Do not use nails or sharp objects to press or rub the suction and blowing ports to prevent damage.
- 5.** Do not use alcohol, nail polish remover, or detergent to clean the product, as this may cause malfunction, breakage, or fading.

## Safety Precautions

To reduce the risk of malfunction, electric shock, injury, fire, death, or equipment and property damage, please follow the precautions outlined below.

### **1. Charging Cable**

- 1.1.** Do not use the charging cable if it is damaged, as it may cause burns, electric shock, or fire due to short circuits.
- 1.2.** Do not unplug or insert the charging wire with wet hands, as this may cause electric shock or injury.
- 1.3.** Do not damage, modify, forcefully bend, pull, twist the charging line, or place heavy objects on the charging cable during use or charging, as this may cause electric shock or fire.
- 1.4.** If the charging cable is damaged, replace it immediately to avoid danger.

### **2. Operating Safety Precautions**

- 2.1.** Do not block or insert foreign objects into the suction and blowing ports during operation, as this may damage the product.
- 2.2.** Do not immerse the product in water.

- 2.3.** Keep the product dry. Do not use it in damp environments.
- 2.4.** Do not use it with wet hands.
- 2.5.** Do not use near flammable materials such as gasoline, paint thinner, or other explosive materials, as this may cause an explosion or fire.
- 2.6.** Do not leave the product turned on when not in use, as it may cause a fire due to a short circuit.
- 2.7.** Do not store the product in a high-heat area.
- 2.8.** Keep away from children and infants.
- 2.9.** Do not store the product in areas such as bathtubs, showers, or sinks where water may be present.
- 2.10.** Do not allow the air inlet to be close to your hair to avoid it being sucked into the fan.

### **3. Exception or Failure**

If you notice any issues, such as no airflow, frequent stops, redness inside, or smoke, stop using the product immediately. Continuing to use it may cause injury or fire due to a short circuit.

## **FCC Statement**

**1.** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)** This device may not cause harmful interference; and
- (2)** This device must accept any interference received, including interference that may cause undesired operation.

**2.** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for assistance.

RF warning statement:

The device has been evaluated to meet general RF exposure requirements.

The device can be used in portable exposure conditions without restriction.

## **Disposal**

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**<https://www.porodo.net/warranty>**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:  
**[info@porodo.net](mailto:info@porodo.net)**

Website: **<https://www.porodo.net/>**

Service Support: **[support@porodo.net](mailto:support@porodo.net)**

Instagram: **[porodo](#)**