

**PORODO** *Blue*



**Porodo Blue**  
**EarBuds**  
**Pro 2**

SKU: PBARPDP2

# Table of Contents

Product Overview	2
Specifications	2
Product Features	3
Operation Instructions	4
Touch Control Functions	5
Package Contents	5
Safety Precautions	5
Disposal	6
Warranty	7
Contact Us	7

## Overview

The Porodo Blue Earbuds Pro 2 are designed to offer a premium listening experience with 20 hours of working time. These earbuds come with advanced features, including wireless charging, independent earbuds for more flexibility, and swipe volume control. With active noise cancellation (ENC) and deep bass technology, they deliver immersive sound quality. Touch control functionality adds ease of use, while Bluetooth connectivity ensures seamless pairing with devices. Whether you're enjoying music, taking calls, or using them for workouts, the Earbuds Pro 2 combines style and performance in one sleek design.

## Specifications

Chipset	JL6973
Speaker	Custom high-excursion driver
Connectivity	Bluetooth v5.3
Distance	25m
Size	21.3 x 44.3 x 53.5 mm
weight	46.2g
Charging case	MagSafe charger, Qi-certified chargers, Lightning connector
Battery	5 hours with a single charge, 20 hours with the charging case

# Product Features

- a. Wireless Charging:** Forget about the hassle of plugging in your earbuds to charge. The Porodo Blue EarBuds Pro 2 supports wireless charging, allowing you to simply place the case on a wireless charger and power up without the mess of cables.
- b. Independent Earbuds:** These earbuds can be used individually, meaning you can use just one earbud while leaving the other in the case. This is perfect for those who prefer to stay aware of their surroundings or want to conserve battery life.
- c. 20 Hours Working Time:** With an impressive 20 hours of battery life, the Porodo Blue EarBuds Pro 2 keeps you going through long listening sessions, workouts, or commutes, ensuring you can enjoy uninterrupted music or calls throughout the day.
- d. Swipe Volume Control:** Adjust the volume without needing to fumble for your phone. The swipe-sensitive feature on the earbuds allows you to control the volume directly by swiping up or down on the earbuds. This provides a convenient, hands-free way to manage your sound.
- e. Active Noise Cancellation (ENC):** The Porodo Blue EarBuds Pro 2 feature Environmental Noise Cancellation (ENC), which actively reduces ambient noise, giving you a more immersive sound experience. Whether you're in a crowded area or on a noisy commute, you'll be able to enjoy your music or calls without interruption.
- f. Touch Control:** With the touch control function, you can easily manage your audio settings and answer or end calls with simple taps on the earbuds. The touch interface eliminates the need for physical buttons, offering a sleek and convenient way to interact with your earbuds.
- g. Deep Bass:** These earbuds are designed with deep bass technology to deliver rich, full sound, making your music more dynamic. Whether you're listening to bass-heavy tracks or more mellow tunes, the Porodo Blue EarBuds Pro 2 offers enhanced audio clarity with a deep, punchy bass that brings your music to life.

# Operation Instructions

## 1. Charging the Earbuds

**a. Charging Case:** Place the earbuds into the charging case. Ensure the case is fully charged using the included USB cable.

**b. LED Indicator:** The LED indicator on the case will show the charging status. A red light means charging, and a green light indicates that the earbuds are fully charged.

**c. Wireless Charging:** The earbuds support wireless charging. Place the case on a compatible wireless charger for easy charging.

## 2. Powering On and Off

**a. Turn On:** Remove the earbuds from the charging case to power them on automatically.

**b. Turn Off:** Place the earbuds back in the charging case to power them off.

## 3. Pairing the Earbuds

**a. First Time Setup:** After turning on the earbuds, enable Bluetooth on your device (smartphone, tablet, etc.). Search for "Blue-AP P2" and select them to connect.

**b. Reconnecting:** The earbuds will automatically reconnect to the last paired device when powered on.

## 4. Volume Control

**a. Swipe Volume:** To adjust the volume, swipe up or down on the touch-sensitive area of the earbuds.

**b. Increase Volume:** Swipe upwards.

**c. Decrease Volume:** Swipe downwards.

## 5. Environmental Noise Cancellation (ENC)

**a. The EarBuds Pro 2 features ENC for clearer calls by reducing background noise.**

**b. Activate ENC:** The ENC feature automatically activates during calls, ensuring optimal sound quality.

## 6. Maintenance and Cleaning

- a. Clean Regularly:** Clean the earbuds and charging case with a soft, dry cloth to remove dirt or earwax.
- b. Avoid Harsh Chemicals:** Do not use harsh chemicals or abrasive materials to clean the product.

## **7. Storage**

Store the earbuds in a cool, dry place when not in use to maintain battery life and prevent damage.

## **Touch Control Functions**

- a. Single tap:** Play, pause, or answer a phone call
- b. Double tap:** Skip forward
- c. Triple tap:** Skip back
- d. Press and hold:** Switch between Active Noise Cancellation and Adaptive Transparency
- e. Swipe up/down:** Adjust volume

## **Package Contents**

Earbuds

Charging case

Lightning to USB-A Cable

## **Safety Precautions**

- 1. Keep out of reach of children:** The earbuds and charging case contain small parts that could pose a choking hazard to children.
- 2. Avoid exposure to extreme temperatures:** Do not expose the earbuds or

charging case to temperatures above 40°C (104°F) or below 0°C (32°F), as it may cause damage to the battery.

**3. Do not use near water:** Keep the earbuds away from water or high moisture environments. Do not submerge them in water.

**4. Do not disassemble:** The earbuds and charging case should not be opened or disassembled. Doing so may damage the product and void the warranty.

**5. Use only compatible chargers:** Always use the provided charging cable or a compatible charger to prevent damage.

**6. Turn off when not in use:** To preserve battery life, turn off the earbuds when they are not in use.

**7. Do not use while driving or operating heavy machinery:** For safety, avoid using the earbuds while driving or operating machinery to ensure full attention is given to the task at hand.

**8. Store in a cool, dry place:** When not in use, store the earbuds and charging case in a dry, cool location away from direct sunlight or heat sources.

## **Disposal**

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at [porodo.net/warranty](http://porodo.net/warranty) and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
[porodo.net/warranty](http://porodo.net/warranty)

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:

**info@porodo.net**

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**