

PORODO



Porodo

Kids WRITING TABLET

SKU: PDLFST082BK


Table of Contents

Product Overview	2
Product Design	2
Instructions for Use	3
Safety Precautions	3
Disposal	4
Warranty	4
Contact Us	4

Product Overview

The Porodo Kids Writing Tablet is an 8.5-inch LCD tracing book designed for children to learn and draw creatively. It features a reusable drawing board with copy cards, allowing kids to trace and practice writing or drawing multiple times. The tablet includes a one-key screen lock for convenience and a child-friendly design that ensures safe and easy use. Ideal for fun learning activities, it encourages creativity while helping develop fine motor and writing skills.

Product Design



Instructions for Use

1. Remove the pen and write directly on the designated area.
2. Press the Clear button and wait 2 seconds before writing again.
3. If the screen fails to clear, replace the battery.
4. To replace the battery, remove the battery cover and insert a new one.

Safety precautions

1. Avoid exposure to rapid temperature changes, temperatures above 40°C or below 0°C. Such conditions may damage the device.
2. Do not expose the product to prolonged ultraviolet light, dust, or high humidity, as these can cause damage to the device.
3. Never allow the device to dip or soak in any liquid, as this can result in permanent damage or malfunction.
4. Avoid using sharp or sticky objects on the screen, and prevent strong impacts or vertical drops, as these can cause irreparable damage.
5. Use a soft, non-dust cloth to gently clean the surface. Do not use abrasive materials, as they can scratch or damage the device.
6. Do not disassemble the product without authorization. Doing so may void the warranty and cause internal damage. Always seek professional assistance for repairs.
7. If the product stops working properly, do not attempt to fix it yourself. Contact our after-sales service department for proper maintenance.
8. If the device fails to clear contents, replace the button battery promptly to avoid malfunction.
9. Never use unsafe or incompatible batteries when the power runs out, as this may lead to malfunction or safety risks.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.porodo.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net
Website: <https://www.porodo.net/>
Service Support: support@porodo.net
Instagram: [porodo](#)