

LèPRESSO



LePresso

**FOAMFLEX HOT & COLD
MILK FROTHER**

SKU: LPCFFMF0099BK

Table of Contents

Product Overview	2
Specifications	2
Product Features	3
Operation Guide	4
Safety Precautions	5
Disposal	6
Warranty	7
Contact Us	7

Product Overview

The Lepresso Foamflex Hot & Cold Milk Frother with Detachable Cup is designed to provide a versatile and convenient solution for creating the perfect froth. Featuring a magnetic drive mixing system, it allows for smooth and efficient frothing for both hot and cold beverages. The detachable stainless steel cup offers easy cleaning and durability, while the multiple frothing options cater to various preferences, including options for chocolate, cold, and latte froths. With a 500ml capacity, it is both functional and user-friendly, making it an ideal addition to your kitchen for achieving creamy and luxurious frothed drinks.

Specifications

Model	LPCFFMF0099
Rated Voltage	220-240V
Rated Frequency	50/60Hz
Rated Power	500W
Capacity	500 ml
Power Cord	UK 3-Pin Plug

Material	SS304, PP&ABS, PS
Product Size	103.4x103.4x191.5mm
Product Weight	680g

Product Features

1. This advanced mixing system ensures a consistent and smooth froth every time. The magnetic drive technology reduces noise and improves efficiency, making it ideal for both hot and cold milk frothing.
2. The frother comes with a high-quality stainless steel cup that is detachable for hassle-free cleaning. The durable material ensures long-lasting use while providing a sleek, modern look. The detachable feature allows for easy pouring and quick cleaning after use.
3. The Foamflex frother offers various frothing options to meet your preferences. Whether you prefer a creamy hot chocolate, a chilled frothy cold drink, or a smooth latte, this frother provides the flexibility to create your favorite beverages with ease.
4. With a 500ml capacity, this frother can serve multiple drinks at once, making it perfect for families or guests. You can easily prepare enough froth for two or more cups of coffee, ensuring you have plenty for everyone.
5. The Foamflex frother is built with durability in mind. Its sturdy construction and easy-to-clean design make it a practical and

low-maintenance addition to your kitchen. Simply detach the cup and clean it without any fuss.

6. Whether you're in the mood for a hot cappuccino or a refreshing iced latte, the Foamflex frother is versatile enough to handle both. It's perfect for preparing frothy milk for a wide variety of drinks, hot or cold, in just a few minutes.

7. The Lepresso frother is designed for ease of use, featuring simple controls and a straightforward operation. Whether you're a coffee enthusiast or just looking to make your first frothy drink, the user-friendly design ensures that anyone can use it with minimal effort.

Operation Guide

1. Setup

Place the frother on a flat, stable surface and plug it into a power outlet. Ensure that the detachable cup is securely attached to the base.

2. Add Milk

Pour milk into the detachable cup. Do not exceed the 500ml maximum capacity for optimal performance.

3. Choose Frothing Option

- a.** Turn the frother on by pressing the power button. Select your preferred frothing option:
- b.** For hot froth: Choose the "Hot" option.
- c.** For cold froth: Choose the "Cold" option.
- d.** For chocolate froth: Select the "Choco" option.
- e.** For latte froth: Select the "Latte" option.

4. Start Frothing

Once you've selected your frothing option, the frother will automatically begin the frothing process. The mixing system will efficiently create a smooth and creamy froth.

5. Wait for Completion

The frother will automatically stop once the frothing is complete. It usually takes around 1-2 minutes, depending on the chosen option.

Safety Precautions

- 1.** Do not submerge the frother base in water or place it under running water. Only clean the detachable cup and base with a damp cloth.
- 2.** The frother and its components may become hot during operation. Use caution when handling, especially when removing the cup or pouring the frothy milk. Allow the frother to cool before handling if necessary.
- 3.** Always monitor the frother while it is in operation to ensure it is functioning properly. Keep the appliance out of reach of children.
- 4.** If any parts of the frother are damaged or malfunctioning, discontinue use immediately. Contact the manufacturer for repair or replacement.
- 5.** Always unplug the frother when not in use or before cleaning to avoid electrical hazards.
- 6.** Ensure the frother is placed on a stable, flat surface to prevent accidental tipping or spilling during operation.

7. After use, allow the frother to cool down before cleaning to avoid burns or damage to the appliance.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **LePresso** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **LePresso** website or store. If **LePresso** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website <https://www.lepresso.com/warranty> and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:

<https://www.lepresso.com/warranty>

Contact Us

If you have any questions or concerns about our Shipping and Returns Policy, please contact us at: info@lepresso.com

Website: <https://www.lepresso.com/>

Instagram: [lepresso_official](#)