

PORODO



Porodo

**4-In-1 Face & Body
Electric Trimmer**

SKU: PDLFST2511WH

Table of Contents

Product Overview	2
Specifications	2
Schematic View	3
Charging Instructions	3
Instructions for Use	3
Cleaning and Maintenance	4
Display Indicators	4
Disposal	5
Warranty	5
Contact Us	5


Product Overview

The Porodo 4-in-1 Face & Body Electric Trimmer is a complete, multi-zone grooming solution with quick-swap heads for facial shaving, body shaving, and precision detailing. Ceramic precision blades deliver smooth, consistent cutting with reduced irritation, while the IPX7 water-resistant design supports safe wet or dry use and simple rinsing. A Smart LED display clearly shows battery level and operating status, and the built-in illumination improves visibility on contours and hard-to-see areas. The rechargeable, cordless design with an ergonomic handle provides comfortable control for everyday maintenance and full-body grooming, at home or on the go.

Specifications

Rated Power	5W
Input	5V/1A
Battery Capacity	600mAh
Working Time	1.5H
Recharge Time	1.5H
Motor Speed	6100RPM
Charging Interface	USB-C
Water Resistance	IPX7
Product Size	29 × 36 × 150mm
Product Weight	115g
Model Number	PDLFST2511WH

Schematic View



1. Body Hair Trimmer Head
2. Power Button
3. Built-In Indicator Button
4. Base
5. Shaver Head and Comb
6. Bikini Trimmer
7. Guide Comb (9-12/3-6mm)
8. Facial Shaver

Charging Instructions

Warning: Be cautious with fast charging adapters exceeding 5V-1A, as they cannot be used.

1. Turn off the machine before charging.
2. Plug the USB cable into a 5V, 1A power adapter to charge the appliance.
3. The display screen will show the charging status.

Instructions for Use

The product is equipped with a travel lock to prevent accidental activation during travel. To activate or deactivate the lock, press and hold the switch for 3 seconds, or connect the power supply to automatically unlock the device.

1. Body Hair Shaving Head: The body hair shaving head is fitted with two comb attachments (3-6mm/9-12mm) for trimming hair on various areas of the body. It can also be used without a comb for more direct trimming.
2. Shaver Head: This head is designed for trimming short hair in areas such as the armpits, legs, arms, and bikini area. After trimming the hair to a shorter length, the shaver head can be used to smooth the skin.

3. Facial Shaver: The facial shaver is intended for the removal of facial hair, including hair around the chin, upper lip, and other areas of the face, leaving the skin smooth and clean.

4. Bikini Trimmer: This head is specifically designed for trimming hair in sensitive areas, such as the bikini line, offering precise grooming for these delicate areas.

Cleaning and Maintenance

- a.** This product is IPX7 waterproof and can be rinsed under water.
- b.** Place under the faucet to flush away residual hair.
- c.** Use the brush to clean any remaining hair on the heads.
- d.** Dry the product thoroughly after washing.
- e.** Attach the head protection cover and store in a cool, dry place.

Display Indicators

- 1.** Electricity percentage: The display shows electricity levels in sequence (100 % /95/90/.../10/05/00). When charging, the percentage increases; when in use, it decreases. If 05 flashes, it indicates a low battery and reminds you to charge. If 00 appears, the battery is exhausted, and the device will shut down.
- 2.** Faucet symbol: The faucet symbol flashes after 30 minutes of cumulative use, indicating that the product needs to be cleaned.
- 3.** Lock symbol: Press and hold the switch for 3-5 seconds to lock the travel lock. To unlock the product, press and hold the switch again for 3-5 seconds or connect it to the power supply.

change the title in formal way for product user manual.



Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.porodo.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: <https://www.porodo.net/>

Service Support: support@porodo.net

Instagram: **porodo**