



Green Lion

JET LIGHTER X

SKU: GNJTLXGSTRCHBK

Model No: GTL53

Table of Contents

Product Overview	2
Specifications	2
Product Design	3
Replacing the Gas Canister	4
Ignition Guide	4
Flame Adjustment	4
Adjusting the Telescopic Handle	4
Safety Precautions	5
Maintenance	5
Disposal	6
Warranty	6
Contact Us	6

Product Overview

The Green Lion Multipurpose Torch Lighter is a versatile and durable tool designed for various outdoor and emergency needs. It features a refillable butane chamber and a zinc alloy case, ensuring long-lasting performance and resilience. The wind-resistant flame provides reliable ignition even in challenging conditions, while the anti-leak valve enhances safety. This lighter offers three lighting modes, with a powerful 1300°C heat, and a built-in flame lock switch for controlled usage. Additionally, it includes practical features such as an emergency window breaker and a built-in bottle opener, making it a multi-functional tool ideal for camping, outdoor adventures, and emergencies.

Specifications

Model No.	GTL53
Material	Zinc Alloy + ABS
Gas Type	Butane Gas
Temperature	1300°C Max
Flame Length	11 cm
Fuel Tank Capacity	12 mL (Approx. 7 g)
Gas Consumption	72g/h
Product Weight	313 g
Torch Dimensions	30*215 mm
Telescopic Rod Dimensions	220*910 mm

Product Design



Replacing the Gas Canister

1. Ensure the lighter is turned off and fully cooled before refueling.
2. Rotate the flame adjustment knob counterclockwise to the minimum setting (toward the "-" mark).
3. Invert the lighter, align the nozzle of the butane gas canister with the gas filling valve located at the bottom, and press firmly to connect.
4. Hold the canister in place for 3-5 seconds, and repeat this process 3-4 times for optimal refueling.

Note: After refueling, the flame may appear unstable temporarily, which is normal. It will stabilize after several ignitions.

Ignition Guide

1. Slide the safety lock button to the unlocked position to prepare the lighter for use.
2. Press the "On/Off Button" to ignite the flame.
3. Slide the "Safety Lock / Flame Lock" button to the left to secure the flame in the locked position for safety.

Flame Adjustment

1. Before or during ignition, rotate the "Flame Adjustment Ring" on the body of the lighter to adjust the flame intensity.
2. Rotate to the Left to decrease the flame.
3. Rotate to the Right to increase the flame.

Adjusting the Telescopic Handle

1. Align the threaded interface at the head of the telescopic rod with the connection port at the tail of the body. Rotate the telescopic rod clockwise until it is securely fastened, allowing it to extend freely to the desired length.

2. The adjustable length includes 430mm, 555mm, 690mm, 815mm, and 915mm (maximum extended length, farthest safe distance).
3. Hold the telescopic rod and gently pull it out or retract it until a "click" sound is heard, indicating it is securely locked in position.

Safety Precautions

To prevent fire, burns, or personal injury, please strictly follow these precautions:

1. This product is not a toy! Keep it out of the reach and access of children.
2. Only capable adults should use this product. Individuals with sensory or mental impairments should not use it.
3. Do not disassemble, modify, or expose the product to severe impacts.
4. Only high-purity butane gas should be used with this lighter. Using improper fuel can cause explosions.
5. Never direct the flame at people, animals, plants, clothing, or any flammable or explosive materials.
6. The flame nozzle and metal parts may become extremely hot during and immediately after use. Allow the product to cool down naturally after use; avoid touching it with your bare hands. Do not use the lighter continuously for more than 10 minutes.
7. Store the lighter in a cool, dry place, away from direct sunlight. Do not place in environments with temperatures exceeding 50°C or below -10°C.

Maintenance

1. Regularly clean the body with a soft cloth to ensure the flame nozzle remains clean and unobstructed.
2. If the lighter will not be in use for an extended period, empty all internal gas before storing it in a cool, dry place.
3. If you experience ignition issues, abnormal flames, or other problems, first check the gas volume to ensure it is sufficient or adjust the flame size as needed.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.greenlion.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: <https://www.greenlion.net/>

Sales: sales@greenlion.net

Service Support: Support@greenlion.net

Telegram: [@greenlion_global](https://t.me/greenlion_global)

Instagram: [@greenlion_global](https://www.instagram.com/greenlion_global)