

**PORODO**  
LIFESTYLE



**Porodo Lifestyle**  
**WALL PLUG-IN**  
**Essential Oil Diffuser**

SKU: PDLFST197

# **Table of Contents**

Product Overview	2
Specifications	2
Product Features	3
Operating Instructions	3
Product Design	4
Installation Guide	4
Replacing the Spray Head Tube	5
Troubleshooting	5
Safety Precautions	5
Cleaning Instructions	7
Disposal	7
Warranty	8
Contact Us	8

## Product Overview

The Porodo Wall Plug-In Essential Oil Diffuser offers a convenient and efficient way to enhance your environment with continuous waterless diffusion, providing a hassle-free experience. It operates at a low 5W energy consumption, ensuring efficiency without wasting power. With a wide coverage range of 200-250m<sup>3</sup>, it can fill rooms of various sizes with a refreshing aroma. The customizable mist intervals allow you to adjust the duration to suit your needs, while the refill indicator light notifies you when it's time to add more oil for uninterrupted use. Featuring a 120mL capacity, this diffuser ensures long-lasting aroma diffusion, and its UK 3-pin plug makes it easy to integrate into your home or office setup.

## Specifications

Capacity	120mL
Area Coverage	200-250m <sup>3</sup>
Rated Voltage	100-240V
Rated Power	5W
Mist Intervals	15s, 30s, 60s
Timer Settings	60s, 180s, 360s
Power Cord	UK Plug
Product Size	79.9 x197.2mm
Model Number	PDLFST197

## Product Features

- 1. Waterless Diffusion:** Provides continuous diffusion without the need for water, ensuring a hassle-free experience.
- 2. Low Energy Consumption:** Operates at just 5W, offering an energy-efficient solution for aroma diffusion.
- 3. Wide Coverage:** Covers areas between 200-250m<sup>3</sup>, making it suitable for various room sizes.
- 4. Customizable Mist Intervals:** Allows you to adjust the misting duration to fit different environments and preferences.
- 5. Refill Indicator Light:** Alerts you when the oil level is low, ensuring you never run out of fragrance unexpectedly.
- 6. High oil Capacity:** Offers extended usage time with its 120 mL oil reservoir.
- 7. UK 3-Pin Plug:** Compatible with UK power outlets for easy installation.

## Operating Instructions

This product offers three mist levels (15S, 30S, 60S) and three timer settings (60S, 180S, 360S), providing customizable mist configurations for aromatherapy to suit individual preferences.

### **1. Powering On/Off:**

To power the diffuser on or off, press and hold the "( >>> )" button.

To select the mist duration (15S, 30S, 60S), press the "( >>> )" button briefly.

### **2. Backlight Control:**

To activate or deactivate the backlight, press and hold the "( ☹ )" button.


### **3. Adjusting the Pause Interval:**

To adjust the pause interval (60S/180S/360S), press the "( ☹ )" button briefly.

### **4. Memory Function:**


The device has a memory function that retains your previous settings. Subsequent use will follow these settings unless the diffuser is unplugged, which will restore the factory default settings (mist duration: 15S, pause interval: 60S).

# Product Design



# Installation Guide

1. Unscrew the lower cover
2. Unscrew the oil bottle to fill or change the essential oils.
3. Screw the oil bottle and the lower cover
4. Plug in the sockets



## Replacing the Spray Head Tube

1. Unscrew the lower cover and refill bottle
  2. Pull old spray head tube out and replace it with a new one
  3. Screw the oil bottle and lower cover back on
  4. Remove the old nozzle, clean it with water, dry it with a cloth, and reinstall it.
  5. Alternatively, replace it with a new nozzle tube to prevent damage to the diffuser.
- NOTE:** Reapply every 30 days or when the spray is no longer strong.

## Troubleshooting

1. Does Not Diffuse:
  - a. Ensure the machine is not in a "non-working period." If it is, it will not spray.
  - b. Check if the air pump is damaged. If it is, replace it with a new one.
2. Sprays Little:
  - a. Verify if the gasket is damaged or loose. Adjust or replace it with a new one if needed.
  - b. Check whether the atomized core is plugged. Clear it with alcohol or replace it with a new one.
3. Oil Spill:




Check if the atomized head is damaged. If so, replace it.
4. Oil Overflow:
  - a. Confirm if the oil bottle is loose. If it is, install it correctly.
  - b. Inspect the gasket of the atomized head for damage. If damaged, replace it.
  - c. Keep the machine vertical. Tilting or laying it flat may cause oil overflow.

## Safety Precautions

1. The diffuser should not be turned or flipped when the oil is inside, this will result in damaging the diffuser.
2. Keep Away from Water: Avoid placing the diffuser in areas with high moisture or

near water sources to prevent electrical hazards.

- 3. Supervision Required:** Never leave the diffuser running unattended for extended periods of time, especially when used with essential oils.
- 4. Use with Caution:** Ensure that the diffuser is plugged into a properly grounded outlet. Do not use it if the cord or plug is damaged.
- 5. Keep Away from Children and Pets:** Ensure the device is out of reach of children and pets to avoid accidents.
- 6. Avoid Overfilling:** Do not overfill the water reservoir. Follow the recommended guidelines for water capacity.
- 7. Turn Off When Not in Use:** Always switch off the device when not in use and unplug it for safety.
- 8. Proper Ventilation:** Make sure the area is well-ventilated when using the diffuser to allow for proper air circulation and diffusion.
- 9. Regular Maintenance:** Clean the device regularly according to the manufacturer's instructions to avoid mold build-up or other health hazards.
- 10. No Essential Oil Overload:** Use only the recommended amount of essential oil to avoid damaging the device or causing unwanted smells.
- 11. Power Off After Use:** Ensure the device is powered off before cleaning or performing maintenance.



## **Cleaning Instructions**

This machine requires cleaning when changing to a different essential oil or if the atomization volume weakens.

- 1.** Unscrew the lower cover and remove the oil bottle.
- 2.** Use a larger container to fill with industrial alcohol, then soak the bottle for 10-15 minutes.
- 3.** Air dry the bottle.
- 4.** Do not alter or disassemble the product, as this may cause damage and void the warranty.
- 5.** Avoid using the product when the temperature is too high or too low. The recommended temperature range is 10°C to 40°C.
- 6.** Ensure the power switch is off when changing the oil.
- 7.** Keep children and pets away from the diffuser.
- 8.** Do not place the diffuser on appliances.
- 9.** Clean the bottle and pipe separately, and avoid immersing the entire diffuser in water.

## **Disposal**

This product must not be disposed of as unsorted household waste.

It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**porodo.net/warranty**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:

**info@porodo.net**

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**