

PORODO



Porodo

RONY

1.83\" Sport Smartwatch

SKU:PDT69

Table of Contents

Product Overview	2
Specifications	2
Operating Instructions	3
Charging Guidelines	3
App Installation	4
Bluetooth Pairing	4
Important Notes	4
Disposal	5
Warranty	6
Contact Us	6

Product Overview

The Porodo Rony 1.83" Sport Smartwatch offers real-time fitness tracking, including steps, calories, and heart rate, all displayed on a large 1.83-inch screen. With an IP67 water-resistant rating, it's built for durability and supports up to 6 days of battery life. Featuring Bluetooth calling, voice assistant integration, and support for over 15 languages, this smartwatch is the ideal companion for fitness enthusiasts who want to stay connected.

Specifications

Watch Case	Plastic, Silicon Strap
Battery Capacity	250mAh
Screen Size	1.83"
Screen Resolution	240 x 284
Flash Memory	64Mb
Charging Time	2h
Working Time	4 to 6 Days
Standby Time	20 Days
Bluetooth Version	5.2
Water Resistance	IP67
Operating System	iOS, Android 10.0 and above.
Model Number	PDT69

Operating Instructions


1. Button

1.1. To power the watch on or off, press and hold the button for 5 seconds.

1.2. Short press the on/off screen to switch functions.

1.3. Rotate the button to switch between functions.

1.4. Double-click on the menu page to enter 3D mode and access a multi-style function menu. Tap to "confirm".



2. Screen

2.1. Slide down to access the shortcut menu page.

2.2. Slide up to view the notification page.

2.3. Slide left to open the main functions pages.

2.4. Slide right to access the menu page.

2.5. Press and hold the watch face to enter 3D mode, swipe left or right to switch between styles, and tap to confirm and return to the watch face interface.

Note:


a. Keep the phone close to the watch. If they become disconnected, refresh the app. If some features are not working, try deleting and reinstalling the app, then reconnect the watch.

b. Make sure the watch is not too tight or too loose, as this can affect the optical sensors.

Charging Guidelines

1. Securely attach the magnetic end of the charging cable to the back of the watch. The charging icon will appear on the screen once connected.

2. After the watch is fully charged, disconnect



the charging cable from the power source.

3. If the watch is not used for an extended period, it is recommended to charge it at least once every 3 months.

App Installation

1. Download and install the "GloryFit" app by scanning the QR code with your phone.

2. Select the correct version for your mobile platform.

3. The app is compatible with iOS and Android versions 10.0 and above.



Bluetooth Pairing

1. Enable Bluetooth on your mobile device.

2. Open the "GloryFit" app and go to Device > Add Device > Search for PDSWT69.

3. Select the watch from the list.

4. Once paired, "Binding is successful" will appear on the screen.

Important Notes

1. This product should not be worn while bathing, swimming, diving, in hot springs, saunas, or during other water activities to prevent damage.

2. Keep the equipment and accessories dry to avoid dirt and bacteria.

3. Do not use a microwave or hairdryer to heat or dry the equipment. Avoid high-temperature environments and placing the equipment in low areas. Do not subject the product to strong impacts, vibrations, or excessive sun, heat, humidity, or open flames.

4. Keep the product away from children and animals to prevent chewing or swallowing. Do not disassemble the device yourself.

5. After charging, disconnect the charging cable from the power source to prevent short-circuiting when in contact with conductive objects.

6. All health data provided by this product is for reference only and should not be used for medical diagnosis.

7. Some features, such as caller ID display and message push, may not be compatible with all smartphone versions.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **<https://www.porodo.net/>**

Service Support: **support@porodo.net**

Instagram: **porodo**