



GREEN LION



Green Lion

**ALL-IN-10000 1mAh
POWER BANK**

SKU: GNAL1PB10K

Model No: GL-PX43

Table of Contents

Product Overview	2
Specifications	2
Product Sections	3
Setup Guide	4
Function Introduction	6
Safety Precautions	7
Disposal	8
Warranty	9
Contact Us	9

Product Overview

The Green Lion All-in-1 Power Bank is a 10,000mAh portable charger that combines multiple features for convenience. It supports fast charging with PD 20W, a 1.53-inch IPS touchscreen for easy navigation, and includes a built-in speaker for enhanced functionality. With 256MB RAM and 4GB ROM, it offers smooth performance for various tasks. Ideal for users on the go, this compact power bank merges power and entertainment in one device, making it a versatile addition to any tech setup.




Specifications

Model No	GL-PX43
Material	ABS+PC
Battery	10000mAh
Display	1.53"
Resolution	360*360
Speaker	4Ω 3W
Mic	4.5 mm
Bluetooth	V5.3
RAM & ROM	256MB + 4GB
Type-C Port Input	5V/3A, 9V/2A, 12V/1.67A (PD20W)
Type-C Port Output	5V/3A, 9V/2A, 12V/1.67A (PD20W)
Type-C Cable Output	5V/3A, 9V/2A, 12V/1.67A (PD20W)

Lightning Cable Output	5V/3A
Charging Time	2.5 Hrs
Working Time	10 Hrs
Product Weight	215 g
Product Dimensions	26*60.6*97.7 mm

Product Sections

1. Display Screen
2. Trim
3. On/Off button
4. Speaker sound hole
5. Type-C comes with built-in cable input/output interface
6. Type-C input/output interface
7. Lightning comes with a built-in cable output interface
8. Mic



1. Charging Instructions

Charge this product, such as: Please use the Type-C interface to connect to the Type-C input port for charging the product.

Charging digital devices: Choose the corresponding built-in cable interface to charge your digital device.

Input

Type-C/ Built-in line	DC 5V \leq 3A 9V \leq 2A 12V \leq 1.5A
--------------------------	--

Output

Type-C Built-in line	DC 5V \leq 3A 9V \leq 2A 12V \leq 1.5A
Lighting Built-in line	DC 5V \leq 3A

2. Screen Operation and Button Functionality

Key Operation: Long Press to Turn On

Click: Return to the previous menu or enter the menu.


Home Touch Gestures: Right Swipe Split Screen Function: Right swipe to enter the custom card.

Left Swipe Custom Card: Left swipe to access the custom card.

Slide Message Notification: Slide up to display notifications. Up to 20 messages can be saved. Slide down to return.

Slide Down Shortcut Bar: Slide down to open shortcuts. Slide up to return.

Long Press the Center of the Screen: Set wallpapers.



key operation

Long press to turn on

Click: Return to the previous level/enter the menu;

3. Download and Connect Apps

Scan the QR code to download the GS Fit app.


After turning on the device and entering the homepage, right swipe to enter split screen mode. Click the "Scan Code Connection" shortcut button, right swipe to scan and download the app QR code for your phone. You can also scan the GS Fit QR code provided on the packaging to jump to the connection and download page (browser, WeChat, etc., can be scanned).

Scan Code Connection: After the device is turned on and enters the homepage, right-click to enter the split screen function, click the "Scan Code Connection" shortcut button, and a QR code will appear to connect. Scan code connection can then be performed in the app.

Connection Reminder: After enabling Bluetooth on the phone, enter the app and directly search for the device to manually connect.



Scan the QR code to
Download GS Fit



Function Introduction

Phone

Address book: Connect to the phone to synchronize contacts on the mobile end;

Dialing: Connect your phone to make a call, which can be done on the watch end;

Call history: Connecting to the phone can synchronize the call history on the mobile end.

Voice Assistant

Connect the mobile app and wake up the phone's voice assistant.

Local Music

Download music on your phone and sync it to your device's local music playback. You can also connect Bluetooth headphones to play music.

Mini Games

Contains four casual games: airplane evasion, airplane battle, dice rolling, and crazy parkour.

Album

Synchronize your phone photo album and view it on WeChat.

Weather

Connect your phone to synchronize weather information.

Alarm Clock

You can set 5 alarm reminders.

E-book

Synchronize downloading e-books from your phone on your device.

Sound Recording

Equipped with mobile recording and local recording functions.

Set up

Includes screen display, sound and vibration, language settings, time settings, page style, call settings, Do Not Disturb mode, power-saving mode, system menu, and more.

Please refer to the physical software for the above functional description. Electronic product software functions will be updated and iterated irregularly!

Safety Precautions

Tips:

Carefully read the instructions before using this product. Incorrect usage or incompatible devices may damage your product.

Avoid using sharp objects that could scratch the surface of the outer shell. Do not throw, shake, press, or attempt to disassemble the product.

If not in use for an extended period, ensure the product is fully charged at least once within 3 months.

Do not use chemicals or harsh cleaning agents to clean this product.

After charging, unplug the connection cable promptly to prevent unnecessary battery consumption.

The product should be kept out of direct sunlight and rain, and protected from severe vibration, impact, or compression.

Store the product in a location with an ambient temperature of -10°C to 45°C and a relative humidity not exceeding %75. Avoid exposure to corrosive substances and sources of fire.

This product must not be disposed of as regular waste. It should be taken to an appropriate battery recycling center.

This product is not suitable for children under 14 years of age and must be used under adult supervision.

Ensure the voltage of the charged product is compatible with the device it is used with.

Do not expose the product to water, high temperatures, or extreme environments.

Do not attempt to disassemble or modify the product, as this may damage the protective casing and cause the battery to overheat, catch fire, or explode.

If you detect an abnormal odor or high temperature (normal use generates heat but it should not be hot to the touch), or if there are changes during use, charging, or storage, stop use immediately and contact the dealer.

The product's lifespan may be shortened if used incorrectly. For any damages or malfunctions due to misuse, the product warranty and manufacturer responsibility will not apply.

Note: Consumers are responsible for any consequences arising from violations of the above warnings. Our company will not be held legally responsible for damages caused by improper use.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.greenlion.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: <https://www.greenlion.net/>

Sales: sales@greenlion.net

Service Support: Support@greenlion.net

Telegram: [@greenlion_global](https://t.me/greenlion_global)

Instagram: [@greenlion_global](https://www.instagram.com/greenlion_global)