



**GREEN LION**



**Green Lion**

**LIORA FINGERPRINT BAG**

SKU: GNLIORAFPBBK

## Table of Contents

Product Overview	2
Specifications	2
Safety Precautions	3
Setup Guide	3
Disposal	5
Warranty	6
Contact Us	6

## Product Overview

The Green Lion Liora Fingerprint Bag combines tech-driven design with smart security features. Made from durable PU leather, it offers instant unlocking via a next-gen capacitive fingerprint sensor and supports up to 10 user access profiles. The bag is water-resistant, equipped with multiple pockets, and features a Type-C charging port. With an LED indicator for easy monitoring and a 180-day standby time, it's designed for users seeking a stylish and secure storage solution for their essentials.

## Specifications

Material	PU Leather
Battery	120mAh
Fingerprint Capacity	10 Sets
Unlock Speed	1 sec
Sensor Type	Capacitive
Charging Port	Type-C
Charging Time	1 Hr
Standby Time	6 Months
Product Weight	325 g
Product Dimensions	120*90*220mm

# Safety Precautions


Charge the product before entering fingerprints. It can be unlocked with any fingerprint before entering, but after entry, it can only be unlocked with the entered fingerprint.

The first fingerprint entered is by default the administrator fingerprint.

The second to tenth fingerprints are for users, and administrator fingerprint authorization is required to add them.

All products require administrator authorization to delete fingerprints. For Bluetooth locks, the app can be used to restore factory settings.

For ordinary locks, the fingerprint must be pressed 10 times, while Bluetooth locks require only 5 presses.



# Setup Guide

## 1. Status indication

- — Indicates blue light
- — Indicates red light
- — Indicates green light
- ↔ ● — Indicates alternating red and blue lights


## 2. Administrator fingerprint settings

● Blue light is on



Next Step →

● Blue light is on



Next Step →

● Green light is on



A. After unlocking, press and hold the fingerprint with any finger until the blue light stays on. Immediately proceed to the next step.

B. Adjust the finger angle with the same finger and repeat the entry for more than 10 times (Bluetooth lock products require only 5 or more finger presses).


C. "The green light stays on for 2 seconds and then goes off, indicating that the administrator's fingerprint has been successfully entered."

● The red light is on

During the entry process, a red light indicates repeated entry at the same location. Adjust the finger position to continue the entry.

### 3. Adding User Fingerprints

● Blue & Red Flashing



Next Step  
→

● Blue light is on




A. After unlocking, press and hold the fingerprint with any finger until the red and blue lights alternate flash to release the finger. Immediately proceed to the next step.

B. Press the administrator's fingerprint to confirm authorization.

● The red light is on

During the authorization process, a red light indicates that the administrator failed to authorize. Please press the administrator's fingerprint again to authorize.

● Blue light is on



Next Step  
→

● Green light is on



Next Step  
→

C. Press the user's fingerprint finger that needs to be added, and continuously press the same finger for 10 or more times. Bluetooth products require only 5 or more finger presses.


D. The green light stays on for 2 seconds and then goes off, indicating that the fingerprint is successfully entered.

● The red light is on

During the entry process, a red light indicates repeated entry at the same location. Please adjust the finger position to continue the entry.

## 4. Delete Fingerprint

● Red flashing



Next Step  
→

● The red light is on




A. After unlocking, the administrator fingerprint holds down until the red light flash (After blue red light finishing is red light flashes). Release the finger. Immediately proceed to the next step.

B. Press the administrator's fingerprint, the red light stays on, and the deletion is successful.

● Red flashing

The red light flashes, and deletion failed. Please press the fingerprint again.

## 5. Low Power Warning



●  
Flashing

When pressing the fingerprint, the green indicator light flashes, indicating that the battery is low. Please charge it in time to prevent the fingerprint lock from stopping working.

## 6. Charging State



● & ●  
Long bright

When charging, open the TYPE-C silicone plug, charge DCSV for about 1.5 hours, and the green light goes out after being fully charged.

After being fully charged, unplug the TYPE-C charging cable, and then cover back the silicone plug to prevent water and dust invade the lock.

Do not use fast charging and high voltage charging when charging.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.greenlion.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**<https://www.greenlion.net/warranty>**

## Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: **<https://www.greenlion.net/>**

Sales: **[sales@greenlion.net](mailto:sales@greenlion.net)**

Service Support: **[Support@greenlion.net](mailto:Support@greenlion.net)**

Telegram: **[@greenlion\\_global](https://t.me/greenlion_global)**

Instagram: **[@greenlion\\_global](https://www.instagram.com/greenlion_global)**