PORODO
LIFESTYLE

Porodo Lifestyle
ACCUSCALE
LUGGAGE SCALE

SKU: PDLFST205BK

Table of Contents

Product Overview

The Porodo AccuScale Luggage Scale is a high-precision digital scale designed to ensure reliable and accurate weight measurements for your luggage. It features a maximum load capacity of 50kg, making it ideal for weighing heavy bags before travel. The scale incorporates a high-precision gauge sensor for exceptional accuracy and includes a tare function for resetting the scale to zero, allowing you to measure just the weight of the contents. Its multi-unit conversion function provides convenient switching between various units, ideal for international travel. Additionally, the scale has an automatic shutdown feature that helps preserve battery life, ensuring it's ready for your next use.

Specifications

Capacity	50kg Max
Battery Type	1x CR2032
Scale Division	0.01kg - 0.02lb- 10g / 1oz
Units Supported	kg, lb, g, oz
Auto Shut-Off	60 Seconds
Net Weight	72g
Product Size	153 x 137 x 29mm
Model Number	PDLFST205

Product Features

1. Max Load Capacity: 50kg, perfect for most luggage sizes.
2. High Precision Gauge Sensor: Ensures accurate weight measurements.
3. Tare Function: Reset the scale to zero to weigh only the contents.
4. Multi-Unit Conversion: Easily switch between units like kg, lb, and oz for international convenience.
5. Automatic Shutdown: Conserves battery life for long-lasting use.
6. Compact and Lightweight: Easy to carry, ideal for travel.
7. Clear Digital Display: Provides easy-to-read measurements.

Battery Installation

1. Remove the battery cover and insert a 3V CR2032 battery into the scale, ensuring correct polarity.
2. The LCD will display "8888" for 3-4 seconds before showing "0.00 kg" (or "0.00 lb" or "0 oz 0g").

Operation guide

1. Power On the Scale
Press the ON/OFF button. The display will show "8888" for a few seconds. Hold the scale vertically until the display reads "0.00 kg".
2. Prepare the Item
Secure the bag or item to be weighed using the appropriate hook and place it on the table.
3. Weigh the Item
Grip the scale handle and lift the item. The scale will display the weight along with a "Hold" indicator in the upper-middle section of the LCD.

4. Weighing Another Item

To weigh a different item, remove the previous item from the scale, press and release the ON/OFF button until the display shows "0.00 kg", then repeat from step 2.

5. Turn Off the Scale

To power off, press and hold the ON/OFF button. If the scale is left on but not in use, it will automatically shut off after 60 seconds.

Weighing Instructions and Unit Conversion

Unit Transition: To switch between kg, lb, g, and oz, power on the scale using the ON/OFF button, then press the UNIT button to select your preferred unit.

a. Tare Function (Weighing with a Container)

If you're weighing an item placed in a container, follow these steps to set the tare on the scale:

1. Weigh the container first as described in previous instructions. The weight will display on the LCD screen.

2. Once the weight is displayed, press the "Hold" button in the upper center of the LCD. Then, quickly lift the container and press the ON/OFF button twice to reset the scale.

3. Now, place the item to be weighed in the container and weigh it according to the instructions provided.

4. Only the weight of the item inside the container will be displayed.

b. ON/OFF Button Functions

Turn the scale on and off

Reset the scale to zero

Set the tare weight

c. UNIT Button Function

Change the unit of measurement (kg/lb/g/oz)

Usage Instructions

1. Maximum Weight Capacity: The scale's maximum weight limit is 50 kg. If the weight exceeds 50 kg, an "Err" (Error) message will be displayed.
2. Avoid Overloading: Weighing items over 50 kg may damage the load cell and impact the scale's accuracy.
3. Low Battery Indicator: When the display shows a battery icon, it indicates low battery power. Replace the battery promptly.
4. Ensure Accuracy: For optimal accuracy, avoid shaking or rocking the scale during use.

Battery Safety Instructions

1. Do not recharge non-rechargeable batteries.
2. Remove expired batteries from the device immediately.
3. Avoid mixing old and new batteries in the same device.
4. Keep batteries away from heat sources, fire, and flames.
5. Remove batteries if the device will not be used for an extended period.
6. Do not short-circuit battery terminals.
7. Ensure correct polarity when inserting batteries.
8. Keep battery terminals and device contacts clean.

Safety Precautions

1. Keep the device away from heat sources, direct sunlight, moisture, water, or other liquids.
2. Do not dismantle the device, as this could lead to a short circuit and expose the user to potential hazards.
3. Avoid using the device if it is wet.

4. Repairs should only be conducted by a qualified electrician.

5. Improper repairs or usage may result in serious risks.

6. This device is not a toy. Keep it out of reach of children.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net
Website: **porodo.net**
Service Support: **support@porodo.net**
Instagram: **porodo**