

PORODO



Porodo

POWERBOOST 50000mAh Power Bank 70cm Retractable Type-C Cable

SKU: PDPBFCH093BK

Table of Contents

Product Overview	2
Specifications	2
Key Features	3
Button Control	3
Charging Instructions	4
Safety Precautions	5
Disposal	6
Warranty	7
Contact Us	7

Product Overview

The Porodo POWERBOOST 50000mAh Power Bank, paired with a 70cm Retractable Type-C Cable, is the ultimate solution for keeping your devices charged while on the go. With a massive 50000mAh capacity, it offers long-lasting power to keep your devices running throughout the day. Featuring fast charging capabilities, it supports 22.5W QC3.0 and PD 20W fast charge, ensuring your devices charge quickly and efficiently. The power bank is equipped with a built-in LED display that allows you to monitor the battery status, and a built-in flashlight easily adds convenience in low-light conditions. It also offers simultaneous charging, so you can charge multiple devices at the same time, saving time and effort. The included 70cm retractable Type-C cable provides a tangle-free solution for charging, making it easy to store and carry. With universal compatibility, this power bank is designed to work seamlessly with most smartphones, tablets, and other devices, making it a versatile and essential accessory for those always on the move.

Specifications

Battery Capacity	50000mAh/185Wh/3.7V
USB-C Input	5V/3A, 9V/2A, 12V/1.5A
USB-C Cable Input	5V/2A, 9V/2A, 12V/1.5A, 18W Max
USB-C Output	5V/3A, 9V/2.22A, 12V/1.67A, 20W Max
USB-C Cable Output	5V/3A, 9V/2.22A, 12V/1.67A, 10V/2.25A

USB-A1/A2 Output	5V/3A, 9V/2A, 12V/1.5A, 10V/2.25A
Multi-Port Output	5V/3A (Max)
Retractable Cable Length	70cm
Size	72 x 73.5 x 163mm
Weight	1090g

Key Features

- 1. 50000mAh Capacity:** Provides long-lasting power for multiple devices.
- 2. Fast Charging:** Supports 22.5W QC3.0 and PD 20W fast charge for quick power-ups.
- 3. LED Display:** Easily monitor the battery status at a glance.
- 4. Built-in Flashlight:** Convenient light source for low-light situations.
- 5. Simultaneous Charging:** Charge multiple devices at once without any delay.
- 6. Universal Compatibility:** Works with a wide range of devices, including smartphones and tablets.
- 7. 70cm Retractable Type-C Cable:** Tangle-free and easy to store, ensuring a clean and organized solution.

Button Control

1. Checking Battery Capacity

Press the button to display the current battery capacity.

2. Controlling the Lamp & Activating SOS Function

2.1 Double-click the button to toggle the lamp on or off.

2.2 After the lamp is on, short-press the button to switch to the SOS emergency function.

3. Turning off the Battery Display

Long-press the button to turn off the battery display.

Charging Instructions

1. Charging the Power Bank:

1.1 Built-In Retractable Cable Charging: The power bank can be charged using the built-in retractable Type-C cable, which supports a maximum PD20W charging speed.

1.2 External Cable Charging: Alternatively, the power bank can be charged via an external Type-C cable connected to its Type-C port, also supporting a maximum PD20W charging speed.

1.3 Charging Progress Indicator: The power bank features a battery indicator that displays the charging progress. When fully charged, the indicator will show 100%. Please ensure to unplug the device once fully charged to avoid overcharging.

2. Charging Your Mobile Devices:

To charge your mobile device, use one of the following methods:

2.1 Built-In Retractable Cable: Connect the power bank to your mobile device using the built-in retractable Type-C cable. This cable supports a maximum output of PD20W.

2.2 External Cable (Type-C to Type-C): You can also connect the power bank to your device using an external Type-C to Type-C cable, ensuring it supports a maximum output of PD20W.

2.3 USB-A to USB-C Cable: Alternatively, you can use a USB-A to USB-C cable, which supports a maximum output of 22.5W (USB-A to USB-C ports). Please note that some devices may require a different cable or adapter than what is included.

Note: When charging multiple devices simultaneously, the charging speed will be reduced to a maximum of 5V/3A.

Safety Precautions

- 1.** If the power bank becomes uncomfortably hot or reaches excessive temperatures during use or while charging, it is critical to disconnect it from both the power supply and any mobile devices without delay. This is important to prevent potential damage to the power bank, connected devices, or even to ensure user safety. Allow the power bank to cool down naturally in a well-ventilated area before reconnecting or resuming use.
- 2.** Do not use or charge the power bank in excessively hot or humid environments.
- 3.** Always use the correct cable for charging your devices. Using incompatible cables may cause overheating or damage.
- 4.** Ensure the charging port is clean and free from debris before connecting any cables.
- 5.** Do not expose the power bank to water, rain, or other liquids. It is not water-resistant and may malfunction or become damaged when wet.
- 6.** Store the power bank in a cool, dry place when not in use. Avoid direct sunlight and high-temperature areas such as next to radiators or in cars.
- 7.** Keep the power bank away from flammable materials to prevent any risk of fire.
- 8.** Do not attempt to open, disassemble, or repair the power bank yourself. Contact authorized service centers for any repairs or issues. Unauthorized disassembly may void the warranty and cause safety hazards, such as electrical shocks or battery leakage.
- 9.** Do not use the power bank if the cable or the power bank itself is damaged. A short-circuit or overload can occur if the power bank is not functioning properly.

10. If the power bank is excessively hot or showing signs of swelling, stop using it immediately and dispose of it responsibly.

11. Handle the power bank gently to avoid accidental drops or impacts. Physical damage can affect the performance or safety of the battery.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**