

PORODO



Porodo
MAGNETIC
Pen For iPad

SKU: PDWKZP027

Table of Contents

Product Overview	2
Specifications	2
Product Features	3
LED Light Functions	3
Product Design	4
Compatibility Table	5
Bluetooth Connection	5
Button Functions	6
Environmental Protection	6
Safety Precautions	7
Package Contents	8
Disposal	8
Warranty	9
Contact Us	9

Product Overview

The Porodo Magnetic Pen for iPad is a versatile and efficient tool, designed for use with iPad models from 2018 to 2024. Featuring zero delay and tilt sensitivity, it allows for a smooth and responsive writing or drawing experience. The pen includes a magnetic attachment feature, enabling convenient storage on the side of your iPad. It also supports Type-C charging, ensuring fast and reliable power replenishment, while the replaceable tip extends the longevity of the device. With its sleek design and advanced functionality, the Porodo Magnetic Pen offers an ideal solution for creative professionals and everyday users alike.

Specifications

Battery Capacity	130mAh
Charging Method	Wired Type-C, Magnetic
Recharge Time	15 Minutes (Type-C)
Working Time	9H Continuous Working Time
Nib Size	1.2mm
Material	Aluminum Alloy
Product Weight	15g
Product Dimension	8.7 x 9.7 x 166.7mm

Product Features

1. Zero Delay: No lag between the pen's movement and the screen response.
2. Tilt Sensitivity: Allows for varying pressure sensitivity depending on the angle at which the pen is held.
3. Magnetic Attachment: The pen can attach magnetically to compatible iPads.
4. Type-C Charging: The pen uses a Type-C charging port.
5. Fast Charging: The pen charges quickly for continuous use.
6. Replaceable Tip: The pen has a replaceable tip for extended longevity.

LED Light Functions

1. Charging:

The charging part is flashing, while the fully charged part stays constantly on.

2. Full Charge:

All LEDs are constantly bright.

3. Running:


The LED light is constantly bright.


4. Low Battery:

The LED light is flashing.

5. Button Function:

The button operation is detailed in the button operation instructions.





NOTE: To replace the pen tip, pinch the tip with your fingers, then rotate the tip counterclockwise until it unscrews the pen tube.

Compatibility Table

iPad Pro 11"	2018-2024 Models
iPad Pro 12.9"	2018-2024 Models
iPad Air 10.9" to 13"	2020-2024 Models
iPad Mini 8.3"	2021-2024 Models
iPad 10TH Gen 10.9"	2022 Model

Bluetooth Connection

1. Enable Bluetooth on your iPad:

Go to Settings > Bluetooth and toggle it ON.

2. Connect the device:

a. In the Bluetooth settings on your iPad, look for "stylus pen" under Other Devices.

b. Tap on the device name to pair it.

3. Confirm the connection:

Once connected, the device will appear under My Devices.

Button Functions

1. Power On/Off:

- a. Press the up or down button to turn on the device.
- b. Press and hold the up or down button for 2 seconds to turn it off.

2. Switching Functions (When connected to iPad via Bluetooth):

- a. Press the up button to toggle between the writing function and the eraser tool.
- b. Double-click the up button to open the multitask page.
- c. Press the down button to return to the previous screen.
- d. Double-click the down button to take a screenshot.

3. Undo Button Usage:

The undo button works with the following apps:

- a. iPad Memorandum
- b. Painter
- c. NotesWriter
- d. Notability
- e. GoodNotes
- f. Procreate

4. Eraser Tool Switch:

The eraser tool switch is available in the following apps:

- a. GoodNotes
- b. Procreate

Environmental Protection

- 1. Do not dispose of this device or its accessories as household waste.
- 2. Please follow local laws and regulations for the disposal of this equipment and its accessories, and support recycling efforts.
- 3. The battery complies with the environmental protection requirements of the EU RoHS directive.

Safety Precautions

1. Avoid Rain or Damp Conditions

Keep equipment and accessories dry. Exposure to rain or damp conditions may cause electrical shock or fire hazards.

2. Temperature Safety

Do not place equipment or accessories in areas with extreme temperatures, either too high or too low, as this may lead to equipment failure, fire, or explosion.

3. Battery Handling

Never disassemble, squeeze, or modify the battery. Avoid inserting foreign objects or puncturing the battery. Do not submerge the battery in water or any other liquids to prevent short circuits, overheating, leakage, fire, or explosion.

4. Device and Accessory Modification

Avoid disassembling or modifying the device, including battery replacement, without authorization. Unauthorized modifications will void the warranty. Please contact customer service if the device fails.

5. Child and Pet Safety

Keep batteries away from children and pets to prevent accidental swallowing, which may result in injury or battery explosion.

6. Cleaning and Maintenance

Do not use harsh chemicals, cleaning agents, or strong detergents. Use only a clean, dry cloth to clean the device or its accessories.

7. Use of Approved Supplies

Only use compatible and approved power supplies and accessories. Using unapproved or incompatible components may cause fire, explosion, or other hazards.

Package Contents

Package Contents

Stylus pen x1

Type-C Cable x1

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**