



**GREEN LION**



**Green Lion**

**BROOKLYN**  
**True Wireless Earbuds**

SKU: GNBKRLNTWS

Model No: GL-TWS80

## Table of Contents

Overview	2
Connection Method	2
Specifications	2
Left Earbud Touch Controls	4
Right Earbud Touch Controls	4
Charging Indicator Light	5
Precautions for Use	5
Troubleshooting	6
Disposal	7
Warranty	7
Contact Us	7

## Overview

Thank you for purchasing the Brooklyn True Wireless Earbuds. These earbuds offer exceptional HiFi sound for an immersive listening experience, equipped with Bluetooth 5.4 for seamless connectivity and IPX2 waterproof protection, making them suitable for all your activities. Enjoy touch control for easy operation, a built-in microphone for clear calls, and voice assistant integration for hands-free convenience. With a 15-hour battery life (including the case) and Type-C charging, you can enjoy uninterrupted audio all day long.

## Connection Method

1. Open the earbud case and place it near your unlocked phone.
2. Wait approximately 8 seconds for Bluetooth to activate.
3. Search for the Bluetooth name GL-TWS80 on your phone and select "Connect."
4. Auto-Connect: Once paired, your phone will retain the connection. Simply remove the earbuds from the case, and they will automatically reconnect.

## Specifications

Model No	GL-TWS80
Material	ABS
Case Battery	200mAh

Earbuds Battery	28mAh
Bluetooth	V5.4
Transmission Range	10 m
Speaker	13 mm
Frequency	20Hz-20kHz
Impedance	32Ω±15%
Sensitivity	3±97dB
Waterproof	IPX2
Charging Port	Type-C
Charging Time	1.5 Hrs
Playtime	4 Hrs
Standby Time	40 Hrs
Product Weight	32 g
Product Dimensions	24.5*45*57 mm

## Left Earbud Touch Controls


**Pause/Play:** Tap once.

**Previous Track:** Triple-tap the multifunction button (left side).

**Volume Down:** Double-tap the multifunction button (left side).

**Reject Call:** Press and hold the multifunction button (left or right side) for 2 seconds.

**Voice Assistant:** Press and hold the multifunction button (left side) for 1.5 seconds.




## Right Earbud Touch Controls

**Pause/Play:** Tap once.

**Next Track:** Triple-tap the multifunction button (right side).

**Volume Up:** Double-tap the multifunction button (right side).


**Reject Call:** Press and hold the multifunction button (left or right side) for 2 seconds.



## Charging Indicator Light

**During Charging:** The indicator light will flash green while the charging case is being charged.

**Fully Charged:** The indicator light will turn orange and remain steadily on when the charging case is fully charged.



## Precautions for Use

1. Use a soft cotton swab to clean the charging contacts of the earbuds regularly, as dirt may affect charging performance.
2. Always use the earbuds as instructed. Environmental factors such as interference may affect connectivity. For a stable connection, keep the distance between your phone and the earbuds within 8 meters.
3. If the earbuds do not connect or experience poor communication, remove the earbuds and reset them before reconnecting. Only use charging adapters within the rated specifications (not exceeding 5V/2A) to avoid damage and warranty issues.
4. Ensure the earbuds are fully charged before use for optimal performance.

## Troubleshooting

**1.** If the earbuds become excessively hot or are damaged during charging, verify that the charger is not exceeding 5V 2A. If it is, replace it with a charger rated below 5V 2A to prevent damage.

**2.** If sound is only heard from one earbud, return both earbuds to the charging case. The earbuds will automatically power off. Open the Bluetooth settings on your phone, cancel the existing Bluetooth pairing, then open the charging case, remove the earbuds, and bring them close to your unlocked phone. Wait approximately 8 seconds, enable Bluetooth on your phone, search for the earbuds' Bluetooth name, and select "Connect" to re-pair.

**3.** No Sound from Earbuds:

**3.1.** Ensure the earbuds are charged and functioning properly.

**3.2.** Check if the volume is set to an appropriate level.

**3.3.** Confirm that the earbuds are properly connected to your phone.

**3.4.** Make sure the earbuds are within the normal Bluetooth range (approximately 8 meters).

**4.** Intermittent Sound:

**4.1.** If you experience intermittent sound, this may be due to signal interference. Move to an area with less interference and try reconnecting.

**4.2.** Ensure the distance between the earbuds and your phone is no greater than 8 meters and that there are no obstacles in the way.

**4.3.** Avoid areas with high-power transmitting equipment or sources of electromagnetic interference, as they can affect signal transmission.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
<https://www.greenlion.net/warranty>

## Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: <https://www.greenlion.net/>

Sales: [sales@greenlion.net](mailto:sales@greenlion.net)

Service Support: [Support@greenlion.net](mailto:Support@greenlion.net)

Telegram: [@greenlion\\_global](https://www.instagram.com/greenlion_global)

Instagram: [@greenlion\\_global](https://www.instagram.com/greenlion_global)