



GREEN LION



Green Lion
ORLANDO True
Wireless Earbuds

SKU: GNORLDTWS
Model No: GL-TWS81

Table of Contents

Overview	2
Specifications	2
Connection Method	3
Left Ear Touch Controls	3
Right Ear Touch Controls	4
Indicator Light	4
Precautions for Use	5
Troubleshooting	5
Disposal	7
Warranty	7
Contact Us	7

Overview

Thank you for purchasing the Orlando True Wireless Earbuds. These earbuds are equipped with HiFi sound quality, Bluetooth 5.4 connectivity, and a built-in microphone for clear communication. The touch control feature provides ease of use, while the voice assistant allows for hands-free operation. The digital display and Type-C charging port offer added convenience, and the dual-microphone ensures superior call clarity. With a 15-hour battery life (with case), the earbuds provide extended listening and usage time. Please ensure to read the manual thoroughly before use to familiarize yourself with the product features and ensure proper operation.

Specifications

Model No.	GL-TWS81
Material	ABS
Case Battery	200mAh
Earbuds Battery	28mAh
Bluetooth	V5.4
Transmission Range	10 m
Speaker	13 mm
Frequency	20Hz-20kHz
Impedance	32Ω±%15
Sensitivity	3±97dB
Waterproof	IPX2

Charging Port	Type-C
Charging Time	1.5 Hrs
Playtime	4.5 Hrs
Standby Time	40 Hrs
Product Weight	36 g
Product Dimensions	27*47.5*59.6 mm

Connection Method

1. Open the earbud case and place it near your unlocked phone.
2. Wait approximately 8 seconds for Bluetooth to activate.
3. Search for the Bluetooth name GL-TWS81 on your phone and select "Connect."
4. **Auto-connect:** Once paired, the phone will retain the connection. Simply remove the earbuds from the case, and they will automatically reconnect.

Left Ear Touch Controls



Pause/Play: Tap once.

Previous Track: Tap three times on the multifunction button (left side).

Volume Down: Double-tap the multifunction button (left side).

Reject Call: Press and hold the multifunction button (left or right) for 2 seconds.

Voice Assistant: Press and hold the multifunction button (left side) for 1.5 seconds.

Right Ear Touch Controls



Pause/Play: Tap once.

Next Track: Tap three times on the multifunction button (right side).


Volume Up: Double-tap the multifunction button (right side).

Reject Call: Press and hold the multifunction button (left or right) for 2 seconds.

Indicator Light

During Charging: The indicator light will flash green while the charging case is charging.

Fully Charged: The indicator light will turn orange and remain steadily on when the charging case is fully charged.



Precautions for Use

1. Use a soft cotton swab to clean the charging contacts of the earbuds, as dirt or debris may affect charging performance.
2. Always use the earbuds as instructed. Environmental factors such as interference may affect connectivity. For a stable connection, keep the distance between your phone and earbuds within 8 meters.
3. If the earbuds fail to connect or communication is unstable, remove and reset the earbuds and accessories before reconnecting. Do not use chargers that exceed the rated current, as this may damage the earbuds and void the warranty.
4. Ensure the earbuds are fully charged before use to maintain proper functionality.

Troubleshooting

1. If the earbuds become excessively hot or are damaged during charging, check if the charger is rated above 5V 2A. If it is, replace it with a charger that is rated less than 5V 2A.
2. If sound is only heard from one earbud, return both earbuds to the charging case. The earbuds will automatically power off. Open the Bluetooth settings on your phone, cancel the current Bluetooth pairing, and then reconnect. Wait approximately 8 seconds, enable Bluetooth on your phone, search for the Bluetooth pairing name, and select it to reconnect.
3. No Sound from Earbuds:
 - 3.1. Ensure the earbuds are properly charged and in working condition.

- 3.2. Confirm the volume level is appropriate.
 - 3.3. Verify that the earbuds are properly connected to your phone.
 - 3.4. Check that the earbuds are within the effective range of your phone's Bluetooth connection.
4. If you experience intermittent sound, it may be due to signal interference. To resolve this, move to an area with less interference, and attempt reconnecting the earbuds.
- 4.1. Ensure the distance between the earbuds and your phone is less than 8 meters, and there are no obstacles in between.
 - 4.2. Avoid areas with strong electromagnetic interference, as it may affect Bluetooth signal transmission.
 - 4.3. Close proximity to electronic devices may also cause signal interference.



Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

<https://www.greenlion.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: <https://www.greenlion.net/>

Sales: sales@greenlion.net

Service Support: Support@greenlion.net

Telegram: [@greenlion_global](https://www.instagram.com/greenlion_global)

Instagram: [@greenlion_global](https://www.instagram.com/greenlion_global)