



GREEN LION



Green Lion

**ULTRA GLIDE PRO
Men's Shaver**

SKU: GNULMNSHVBK

Model No.: GL-TM34

Table of Contents

Precautions for Use	2
Specifications	3
Product Overview	3
Charging Instructions	4
Instructions for Operation	5
Cleaning and Maintenance	6
Troubleshooting	8
Disposal	8
Warranty	9
Contact Us	9

Precautions for Use

The instruction manual has been carefully prepared to help you use this electric razor correctly. Please read it thoroughly before use. Following these simple guidelines will not only ensure optimal performance but also extend the life of the shaver.

Danger

Keep the charging cord dry.


Warning

- 1.** Before connecting the power supply to the product, ensure the voltage marked on the product matches that of the local power supply.
- 2.** Do not charge the shaver at temperatures below 0°C or above 40°C, as this could shorten the battery life.
- 3.** This product can only be charged with the provided matching charging cable. Do not use any accessories not supplied by the company.
- 4.** If the power cable is damaged, it must be replaced with a special flexible line or a component from the manufacturer or maintenance department.
- 5.** If the product body has stains, use a soft cloth with neutral detergent to wipe it. Avoid using alcohol, gasoline, or other chemicals to clean the product.
- 6.** If the product is charged under abnormal conditions (such as unusual odor, temperature, or sound), immediately disconnect the power supply and stop using the product. Handle the fault according to its type, and if necessary, send the product to the company's maintenance department for inspection.

Specifications

Model No	GL-TM34
Material	ABS+Stainless steel
Motor	FF-280PA-2961V
Blade	Stainless Steel
Battery	600mAh
Power	5W
RPM Range	8000 RPM
Charging Port	Type-C
Charging Input	DC 5V 1A
Charging Time	1.5 Hrs
Working Time	60mins
Product Weight	178 g
Product Size	65.15x45.3x161.4 mm

Product Overview





Charging Instructions

1. To get started, plug the Type-C connector of the charging cable into the charging port at the bottom of the device. Then, connect the other end of the cable to the adapter and plug the adapter into a power socket, as shown in Figure 1.

2. Once powered on, you'll see the digital display on the body of the device, and the charging indicator () will begin flashing.


3. For the first use, it's important to fully charge the device, which will take around 1.5 hours. When the charge is complete, the digital screen will display "100" and remain steady, and the charging indicator () will turn off. To keep your device in great condition, be sure to remove the battery from the power base once fully charged, and only reconnect it when the battery is depleted. Avoid leaving the device plugged in continuously after it's fully charged.

4. After a full charge, the device can be used continuously for about 1 hour. If you notice the digital screen showing "<5", the charging indicator will flash, indicating it's time to recharge as the power is running low.



Instructions for Operation

- 1.** The product comes locked from the factory. To unlock it, simply press and hold the on/off button for 2 seconds.
- 2.** When the product is locked, pressing the on/off button once won't start it. If the travel lock indicator is flashing, the product remains off.
- 3.** Locking Function: To lock the device, press and hold the on/off button for 2 seconds. The nixie tube will count down (1,2,3), and the travel lock indicator () will flash for 3 seconds before turning off. To unlock, press and hold the on/off button again for 2 seconds. Once unlocked, the product will power on immediately.
- 4.** Shaving: Remove the protection cover shown in Figure 3. Press the on/off button on the shaver, and the digital screen will display the remaining power for 1 second, along with the "POWER LEFT" indicator. Move the shaver gently along the direction of hair growth, keeping the motion straight and smooth for the best results. If you move the shaver too quickly, you may not achieve optimal results. In that case, press the on/off button to turn off the device, and all indicators will go dark.
- 5.** Sideburns trimming: The razor includes sideburn combs at the back. To use them, gently push the sideburn plate to reveal the combs, then trim your sideburns as needed.
- 6.** Dry Shaving: It's best to use the shaver with dry skin. For first-time use, you may notice some mild irritation like redness or tingling, which is completely normal. Your skin will adjust within a week, so be patient as you get used to the



Tips:





When using the shaver, make sure the mesh is held parallel to your face to avoid accidental skin cuts from the central mesh.

Cleaning and Maintenance

1. To clean the shaver, first separate it from the charging line and turn it off. Press the buttons on both sides, remove the shaving head, and clean the shaving head, the round blade, and the body using a small brush. You can also rinse the product directly under the faucet with warm water, but avoid using water above 60°C.

2. After cleaning, hold the shaver firmly, shake off any excess water, and place it horizontally to dry naturally. Once all parts are dry and the shaving head is clean, reattach the shaving head.

3. Store the shaver in a storage bag after cleaning to protect it from surface damage.



Troubleshooting

Problem	Possible Cause	Solution
The blade is not sharp, rotates weakly, and can be used for fewer times	The blade is damaged and dirty, and the power is inadequate	Blade replacement, cleaning, and charging
It cannot be charged and doesn't work upon power-on	The shaver or adapter is damaged, the power is fully consumed, and the on/off button fails	Contact a service center for repair.
The display screen doesn't turn on	Display screen/circuit fault	Contact a service center for repair.

Disposal



Environmental Protection: The built-in rechargeable battery contains materials that may be harmful to the environment. Before disposing of the shaver, please make sure to remove the battery. Alternatively, you can deliver the product to an official recycling station or send it to the Company's designated maintenance department, where the battery will be safely recycled.

Battery Removal: To remove the battery, first turn off the power and allow the shaver to fully discharge. Then, unscrew all screws on the charging base, remove the plastic parts, and carefully take out the battery.

Warning: Always remove the rechargeable battery before discarding the electric shaver to ensure safe disposal.

Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

<https://www.greenlion.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: <https://www.greenlion.net/>

Sales: sales@greenlion.net

Service Support: Support@greenlion.net

Telegram: [@greenlion_global](https://t.me/greenlion_global)

Instagram: [@greenlion_global](https://www.instagram.com/greenlion_global)