PORODO

Porodo Lifestyle
Wireless Mirroring Multi-Angle Projector

SKU: PDLFST102BK

Table of Contents

Safety Precautions

Please read this manual carefully before use and keep it for future reference.

1. The projector is not dustproof or waterproof.

2. To minimize the risk of fire or electric shock, do not expose the projector to rain or fog.

3. Use only the original power adapter. The projector should operate under the specified rated power supply.

4. When the projector is in use, avoid looking directly into the lens. The intense light may cause temporary discomfort or eye strain. Children should use the projector under adult supervision.

5. Do not obstruct the projector's vents. Blocked vents can cause overheating and potential damage.

6. Regularly clean the projector's vents, as dust buildup can impair cooling performance.

7. Do not use the projector in greasy, damp, dusty, or smoky environments. Exposure to oil or chemicals can lead to malfunction.

8. Handle the projector with care during daily use.

9. Always power off the projector if it will not be in use for an extended period.

**10.** Non-professionals are prohibited from

Product Overview

Focus Wheel — Lens — Air Inlet — Rotate

Remote Control Diagram

ON/OFF — Mute

Miracast — Switch to Mouse Control

AirPin

Arrow Keys — OK

Menu

Return — Home

Volume + / –

Access Applications

1. Click on "My Apps" to view installed programs. Click on the program icon to switch between applications.

2. Move to "My Apps" and press OK to enter.

**3.** All apps can be clearly distinguished by their icons.

Settings

Enter the settings menu to configure the following: Networking Settings, Bluetooth Settings, Language Settings, Other Settings, Projection Settings, Audio Settings, Date and Time Settings, and About Device.

Networking Settings

1. Go to Settings > Networking Settings.

2. Toggle Wi-Fi to ON.

3. Select your desired Wi-Fi network (SSID) from the list.

**4.** Enter the password and connect to the internet.

Bluetooth Settings

1. Go to Settings > Bluetooth Settings.

2. Toggle Bluetooth to ON.

3. Click Refresh Device to search for available devices.

4. Select your desired device to pair.

Language Settings

1. Navigate to Settings > Language Settings.

2. Select your preferred language and input method.

Other Settings

1. Access Settings > Other Settings.

2. Manage Application Settings, Factory Reset, and Developer Options.

Projection Settings

1. Go to Settings > Projection Settings.

2. Configure the projection mode and adjust the keystone correction.

3. Use the Screen Zoom option for further adjustments.

Audio Settings

1. Navigate to Settings > Audio Settings.

2. Adjust the audio volume and sound preferences.

Date and Time Settings

1. Navigate to Settings > Date and Time Settings.

2. Adjust the Time zone, Time Format, Date Format, and Date and Time according to your preferences.

Signal

After connecting the projector to another output device, select HDMI or Audio/Video from the options displayed.

Miracast Guide

Ensure that the Android devices (phone, tablet, etc.) are connected to the same local wireless LAN as the projector.

1. Operations on Devices:

From the Home Screen, navigate to My Apps > Miracast > Open Miracast Service. Turn on Phone Mirroring and select Connection.

Miracast

1. Open the settings menu on your Android Mobile/Pad
2. Access your display settings or screen mirroring.
3. Select Your Miracast receiver.

2. Operations on Android Devices:

← Easy Projection ⑦

Wireless Projection

AVAILABLE DEVICES

Searching for devices....
Make sure that projection is enabled on the
external display.

STOP SEARCHING

AirPlay Guide

Ensure that Apple devices (iPhone, iPad, etc.) are connected to the same local wireless network as the projector.

1. Operations on Devices:

From the Home Screen, go to My Apps > AirPin > Open AirPin Service. Enable Phone Mirroring and select Connection.

2. Operations on iPhone Devices:

Open the Control Center on your iPhone. Tap Screen Mirroring and select the device for mirroring.

Precautions

1. Please review all information related to the operation and maintenance of the projector. Carefully reading this manual will help avoid issues. Following these safety guidelines will extend the life of the projector.

2. Consult professional personnel for installation and repair services. Do not use damaged cables, accessories, or other peripherals.

3. The projector should be kept away from flammable materials, explosives, and strong electromagnetic interference (e.g., large radar stations, power stations, substations). Avoid placing the projector under direct sunlight or in areas with strong ambient light.

4. Never cover the projector's vents.

5. Always use the original power adapter.

6. Ensure proper ventilation and avoid covering the projector's vents to prevent overheating.

7. When the projector is in use, do not look directly into the lens, as the intense light may cause temporary eye discomfort.

8. Do not bend or drag the power cord.

9. Avoid placing the power cord under the projector or heavy objects.

10. Do not cover the power cord with soft materials.

11. Never subject the power cord to heat.

12. Do not touch the power adapter with wet hands.

Caution: Keep the product away from children.

Warning

Do not look directly into the lens while the projector is in use, as the intense light may cause eye discomfort or damage. Children should operate the projector only under adult supervision.

Specifications

|	
Projector Power	50W
AC Input	100–240V, 60/50Hz
DC Input	27V/1.1A, 5V/2A
Display System	2.69" LCD
Operating System	Android 11.0
CPU	Allwinner H713
RAM	1GB + 8GB
Connectivity	WiFi 2.4GHz, Bluetooth

Projection Area	40-130 Inches
Projection Distance	1.2-3.5m
Resolution	1920x1080 (FHD) / 4K Resolution Support
Throw Ratio	1.37:1
Aspect Ratio	Native 16:9 & 4:3
Contrast	1500:1 FOFO
Mirroring	AIRPLAY, MIRACAST
Brightness	150-200 ANSI Lumens
Lamp Type	LED
Lamp Lifetime	>50000hrs (Medium Brightness)
Built-in Speaker	3W
Interface	HDMI, 3.5mm AUX Jack, USB-A
Net Weight	580g
Dimensions	106 x 106 x 192mm
Model Number	LFS102

Disposal

This product must not be disposed of as unsorted household waste.

It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net
Website: **porodo.net**
Service Support: **support@porodo.net**
Instagram: **porodo**