

PORODO



Porodo

BALI
10000mAh Power Bank

SKU: PDPBFCH0105

Table of Contents

Product Overview	2
Specifications	2
Product Components	3
Charging Instructions	3
Safety Instructions	4
Material Content	5
Troubleshooting	6
FCC Statement	7
Disposal	8
Warranty	9
Contact Us	9

Product Overview


The Porodo Bali 10000mAh Power Bank is a compact, everyday charging solution designed for people who want less clutter and more convenience. With both built-in Lightning and USB-C cables, it removes the need to carry extra wires while staying ready to charge multiple devices at once. Supporting up to 22.5W fast charging, it delivers quick power boosts whether you are commuting, traveling, or moving between meetings. Its travel-friendly size, integrated strap for easy carrying, and ability to charge devices simultaneously make it a reliable companion for modern, on-the-go lifestyles where staying powered matters.

Specifications

Material	ABS+PC
Battery Capacity	10000mAh
USB-C Input	5V/3A, 9V/2A, 12V/1.5A, 18W Max
USB-C Output	5V/3A, 9V/2.22A, 12V/1.67A, 20W Max
USB-C Cable Output	5V/3A, 9V/2A, 10V/2.25A, 12V/1.5A, 22.5W Max
Lightning Cable Output	5V/2.4A
Total Output	5V/3A, 15W Max
Working Temperature	0°C to 35°C
Cable Lengths	16cm (USB-C), 7cm (Lightning)
Product Weight	188g
Product Size	30.3 x 63.65 x 80.1mm
Model Number	PDPBFCH0105

Product Components

1. Type-C Cable Output
2. Lightning Cable Output
3. Switch Button
4. Display Screen
5. Type-C Input/Output



Charging Instructions

1. When the power bank is being charged, the digital display flashes and shows the current power level.
2. Once fully charged, the display shows "100," and the indicator light remains on.
3. When charging other devices, the digital display remains on and shows the current battery percentage.
4. When the battery level drops to 0%, the display shows "0%" and flashes at a rate of 1 Hz to indicate a low battery level.
5. If the battery voltage falls below 3V, the power bank will automatically shut off.

Safety Instructions

1. Place the product on a flat surface during use.
2. If the product comes into contact with the human body, the contact time should not exceed 10 seconds.
3. The operating temperature range of the product is 0°C to 35°C, and use above 35°C or below 0°C is not recommended.
4. Do not expose the product to fire or water, and do not clean it with a damp cloth to prevent leakage, short circuits, or malfunction.
5. Do not cover the product with paper or other objects, as this may obstruct heat dissipation and cooling.
6. Do not leave the product unattended during use.
7. Do not disassemble the device yourself, as it contains no user-serviceable parts.
8. Do not drop, shake, strike, or squeeze the product.
9. Avoid short-circuiting the anode and cathode to prevent fire hazards.
10. Keep the product out of the reach of children.
11. Before use, ensure that the charger output voltage matches the product requirements, as mismatched voltage may cause overload, smoke, fire, or other dangers.
12. If you're using a power adapter, ensure it is CCC certified and meets applicable safety standards.
13. Unplug the charger once the product is fully charged.
14. If abnormal conditions occur during use, such as unusual odor, excessive heat, discoloration, deformation, or leakage, stop using the product immediately.
15. Do not use the product after it has been exposed to water.
16. Improper battery replacement may result in a risk of explosion.
17. Only the same or equivalent battery type should be used, and replacement must be performed by qualified maintenance personnel.
18. Batteries should not be exposed to sunlight, fire, or other sources of excessive heat.
19. Please do not hang the power bank from the charging cable.

Declaration of Hazardous Substances in Electronic and Electrical Products						
Component Name	Pb	Cd	Hg	Cr6+	PBBs	PBDEs
Shell	○	○	○	○	○	○
PCB	×	○	○	○	○	○
Battery	○	○	○	○	×	×
Screw	○	○	○	○	×	×
Metal Components	○	○	○	○	–	–
Data line	○	○	○	○	○	○

This table is prepared in accordance with the requirements of SJ/T 11364.
 ○ Indicates that the content of toxic and hazardous substances in all homogeneous materials of the component complies with the limit requirements specified in GB/T 26572.
 × Indicates that the component marked with × contains toxic and hazardous substances that exceed the limit requirements specified in GB/T 26572 in at least one homogeneous material. Due to current technical limitations, substitution is not possible. With future technological advancements, replacement or improvement will be achieved.
 – Indicates that, according to GB/T 26572, there are no requirements for the content of PBBs and PBDEs in metal components.

The environmental protection use period of this product under normal operating conditions is 5 years.
 Indicates that the product or its packaging is recyclable.
 Pay attention to fire prevention and do not use the product in high-temperature environments.
 Arbitrary disposal is prohibited to avoid environmental pollution.

The “hazardous substances” listed in this table will not cause harm to human health or the environment when the product is used under normal conditions.

The “hazardous substances” and related component information provided in this table are intended to inform consumers and recycling professionals of the presence of relevant substances, supporting proper and environmentally responsible disposal of the product.

Troubleshooting

1. Problem: Indicators do not display a full charge after extended charging.

Reasons:

- a.** Insufficient charging time
- b.** Adapter or product malfunction

Solutions:

- a.** Charge the product for 12 hours.
- b.** Contact the distributor or after-sales service.

2. Problem: The remaining battery level cannot be detected.

Reasons:

- a.** The battery is fully depleted.
- b.** Power button or indicator malfunction
- c.** Internal power failure

Solutions:

- a.** Recharge the product.
- b.** Contact the distributor or after-sales service.

3. Problem: The product cannot charge other devices.

Reasons:

- a.** Low battery level of the product.
- b.** No power transmission through the USB cable or adapter.
- c.** Incompatible or improper adapter selection.
- d.** Internal power management protection is activated.

Solutions:

- a.** Recharge the product.
- b.** Replace the USB cable or adapter.
- c.** Use a compatible connector suitable for the product.
- d.** Verify device compatibility.

4. Problem: Product charges devices but does not fully charge them.

Reason:

The product battery is depleted.

Solution:

Recharge the product.

5. Problem: Product suddenly stops working or shows no power while charging devices.

Reason:

External short circuit or overload triggers automatic self-protection.

Solution:

Recharge the product to reactivate it.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference; and

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for assistance.

RF warning statement:

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.porodo.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: <https://www.porodo.net/>

Service Support: **support@porodo.net**

Instagram: **porodo**