

PORODO
LIFESTYLE



Porodo Lifestyle
Portable Electric
Shower Pump

SKU: PD-LFST021

Table of Contents

| | |
|----------------------|---|
| Safety Instructions | 2 |
| Instructions for Use | 2 |
| [A] Power On/Off | 2 |
| [B] Operation Modes | 2 |
| Usage Precautions | 3 |
| Troubleshooting | 3 |
| Setup Instructions | 4 |
| Specifications | 5 |
| Warranty | 5 |
| Contact Us | 5 |

Safety Instructions

1. Please read the instruction manual carefully before use.
2. Keep out of the reach of children, infants, and pets.
3. Do not operate the water pump until it is submerged in water.
4. Remove the water pump from water when not in use.
5. The pump contains electronic components and sensors that may be damaged if submerged and not use for extended periods.
6. Normal operation will not affect the functionality of the water pump.

Instructions for Use

[A] Power On/Off

1. Press and hold the power button to activate.
2. To turn off the water pump, press and hold the power button for 2 seconds.

[B] Operation Modes

This unit features three adjustable settings:

- a. The yellow light indicates level 1.
- b. The blue light indicates level 2.
- c. The green light indicates level 3.



Usage Precautions

1. When using, ensure the small water pump is completely submerged in water and position the excess water pipe in the bucket or basin.
2. The small water pump is designed solely for pumping water and does not have a heating function. Please prepare hot water separately if required.
3. To prevent damage to the pump from running dry, turn off the power promptly when the water in the bucket is depleted.
4. The pump is not charged upon purchase. Please charge the water pump after acquiring the machine.
5. To charge the pump, connect it to a mobile phone charger or a regular charger using the charging cable. Ensure the plug is securely fastened during charging.

Troubleshooting

Normal operation description: The pump operates with a sound and the indicator light is on.

Reason for not operating: Stagnant water and air mixed in the pump pipe require air to be expelled.

Solutions:

Method 1: Place the pump in water and wait for more than 10 seconds before starting, allowing the water to fill the pump cavity.

Method 2: Lay the shower head on the ground so that the water level is lower than the water pump, which allows the air to be automatically expelled. Then, turn on the water pump and the shower can be lifted.

Method 3: Ensure the shower head switch is on. Turning off the shower switch can also result in no water flow.

Tips: When using the pump, keep the excess shower hose inside the basin or bucket, and avoid pulling the hose over the edge of the container on the ground, as this can prevent the pump from drawing water.

Setup Instructions

Step 1: Unpack the package. You will find the accessories as displayed in the image.



Step 2: Install the seal ring in the hose, then attach the PVC shower hose to the shower head. Insert the other end of the hose into the water pump.



Step 3: Place the water pump into the bucket and submerge it completely. Turn on the power to start the shower.



Specifications

| | |
|------------------|--|
| Input | 5V-12V |
| Battery Capacity | 7800mAh |
| Recharge Time | 7h |
| Working Time | 2.5h |
| Power | 90W (Max) |
| Accessories | USB Charging Cable, Adhesive Hook, Bath Sponge, Hose, Shower Head, Toilet Bidet Attachment |

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**