

PORODO
LIFESTYLE



Porodo Lifestyle

**Light Therapy
Scalp Massager Comb**

SKU: PDFLSTF1WH

Table of Contents

Product Overview	2
Product Features	2
Schematic View	3
Specifications	4
Operation Guide	4
Usage Instructions	5
Safety Instructions	7
Disposal	8
Warranty	8
Contact Us	8

Product Overview

The Porodo Light Therapy Scalp Massager Comb features EMS scalp activation, three-mode light therapy, and soothing vibration massage for enhanced scalp health. With a rolling oil applicator and 8mL oil container, it ensures even product distribution. The comb offers Type-C fast charging and an auto-shutoff function for convenience and safety, providing a relaxing and effective scalp care experience.

Product Features

- 1. Electric Muscle Stimulation:** This feature improves blood circulation and stimulates hair follicles, promoting healthier hair growth.
- 2. Rolling Bead Liquid-Conducting:** The rolling beads ensure even and controlled distribution of liquid treatments for optimal scalp nourishment.
- 3. Red, Blue, Purple Light:** The comb offers three light therapy modes, red, blue, and purple, each targeting different scalp needs for a customized treatment.
- 4. Silicone Multi-Contact Massage:** The silicone multi-contact massage provides a soothing and relaxing sensation while massaging your scalp, enhancing comfort during use.
- 5. High-Frequency Vibration:** The high-frequency vibration helps relieve tension, soothe the scalp, and improve overall scalp health.
- 6. Independent Liquid Container:** The comb features an independent liquid container, allowing for easy and efficient application of hair treatments without any mess.
- 7. Standing Design:** The practical standing design makes it easy to store and use the device, offering added convenience.
- 8. Type-C Charging Port:** Equipped with a Type-C charging port, the comb ensures fast and efficient charging for a hassle-free experience.

Schematic View



Specifications

Input	DC 5V
Battery Capacity	1200mAh
Rated Power	1.5W
Recharge Time	3H
Working Time	2H
Liquid Tank Capacity	8mL
EMS	3 Intensity Levels
Light Therapy Modes	Red, Blue, Purple LEDs
Vibration Modes	3 Speed Gears
Product Size	47 × 48 × 208mm
Net Weight	116g
Model Number	PDFLSTF1

Operation Guide

1. Power Button / LED Button:

a. Long Press: Power the device on or off.
b. Short Press: Cycle through LED light colors (Red, Blue, Purple) or turn off the LED light.
2. EMS Button:
Short Press: Switch between EMS gear levels or turn off the EMS function.
1st Gear: Red
2nd Gear: Blue
3rd Gear: Purple

3. Vibration Button:

Short Press: Switch between vibration levels or turn off the vibration.

1st Gear: Yellow

2nd Gear: Green

3rd Gear: Red

4. Battery Indicator:

a. In Working State (Standby): White light remains on, indicating the device is ready for use.

b. Low Battery: Red light flashes, signaling that the device needs charging.

c. Charging: White light flashes while the device is charging.

d. Fully Charged: White light remains on when the device is fully charged.

Usage Instructions

Tips:

1. Recommended Usage: Use 3 times a week, for about 15 minutes each time.

2. First-Time Users: If you are new to the product or adjusting to it, start on the low setting with moderate pressure.

3. Essence Viscosity: For optimal performance, use a low-viscosity liquid or one with a strong fluidity. Different essences have varying composition and viscosity, which can affect uniformity and liquid speed.

4. Cleaning: Clean the liquid container immediately after use to avoid residue, dryness, and blockages.

a. Liquid Container - Using Steps



1. Open the lid



2. Add nutrients



3. Close the lid

b. Liquid Container - Cleansing Steps



1. Press down the liquid container



2. Open the lid, rinse it with water and dry the container




3. Put it back

c. Main Device - Using Steps

Tip: After adding hair care products, make sure the device contacts the skin. Press several times to remove any air before use.



Step 1: Long press  to turn the device on.



Step 2: Place the device at the temporal bone (from the temple to the back of the head).



Step 3: Comb through the head center line (from forehead to the back of the head).



Step 4: Move the device along the hairline (back and forth on both temples, passing the hairline).



Step 5: Focus on the top of the head (from the top of the head to the back of the head).



Step 6: After finishing hair care, long press to turn the device off.

Safety Instructions

1. **Charging:** After receiving the device, please fully charge it before use.
2. **Operation While Charging:** The product cannot be turned on while charging.
3. **Damaged USB Cable:** If the USB charging cable is damaged, replace it immediately.
4. **Charging Time:** The charging time is approximately 3 hours.
5. **Automatic Shutdown:** The device will automatically shut down if no button operation occurs within 10 minutes.
6. **Water Resistance:** The product is not waterproof. Do not expose it to water, rain, or moisture.
7. **Flammability:** Do not use the product near flames or explosives.
8. **Disassembly Warning:** Do not disassemble or modify the device. It is strictly prohibited to use it under damaged conditions.
9. **Storage Instructions:** Place the device in a dry, ventilated area, away from direct sunlight and corrosive chemicals.
10. **Long-Term Non-Use:** If you do not use the device for a long time, make sure to charge it at least once every 6 months.
11. **Battery Disposal:** The device has a built-in lithium battery. Please discard it according to local regulations.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.porodo.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: <https://www.porodo.net/>

Service Support: **support@porodo.net**

Instagram: **porodo**