

PORODO



Porodo

HYPE Smartwatch with Earbuds

SKU: PD-HYPE

Table of Contents

Features	2
Tips	2
Package Contents	3
Schematic View	3
Charging Instructions	3
App Connectivity	4
Button Guide	5
Disclaimer	5
Specifications	6
Watch Functions	7
Additional Features	8
Precautions	8
Pairing Earbuds with Phone	9
Pairing Earbuds with Each Other	10
Earbud Instructions for Use	11
Earbud Usage Precautions	12
Troubleshooting	12
FCC Compliance Statement	15
Warranty	16
Contact Us	16

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Features

1. The smart watch features a 1.52" display, offering clear and vibrant visuals for easy navigation and viewing.
2. Integrated Bluetooth functionality allows for hands-free calling directly from the watch, ensuring connectivity and convenience without needing to access your smartphone.
3. With an IP67 rating, the watch is water-resistant, making it suitable for use in various weather condition.
4. The earbuds are designed for full in-ear wear, providing a painless and comfortable experience even during extended use.
5. Crafted with meticulous metal workmanship and equipped with advanced noise reduction technology, the earbuds deliver exceptional sound clarity.
6. Utilizing stable, high-quality Bluetooth 5.0, the device ensures a consistent and robust connection for uninterrupted audio and communication.
7. The earbuds fit into the watch's compartment, which doubles as a charging station, making it easy to carry, store, and keep your earbuds powered up on the go.
8. The earbuds support AI voice commands like Siri activation, adding to the hands-free convenience by allowing voice-operated functionalities.


Tips

1. Please charge the product for approximately 4 hours before using it for the first time.
2. If you do not use this smartwatch regularly, please ensure it is charged at least once a month to maintain battery health.
3. Keep the sensor close to the skin during measurements to avoid inaccurate readings due to movement.
4. The measurements provided by this product are for reference only and should not be used for medical purposes or as a sole basis for health decisions.
5. Some data, such as time, weather, steps, and sleep tracking, will synchronize with your phone or network data after connecting to the phone via the accompanying APP. These settings cannot be manually adjusted.


Package Contents

1. HYPE Smartwatch
2. Earbuds
3. Charging Cable

Schematic View



Charging Instructions



After the magnetic cable is successfully connected, the watch will display the charging icon while the other end is connected to a standard USB port.

Attention

1. Avoid charging the watch in humid or wet environments to prevent damage.
2. Ensure that the watch body and the metal contacts on the magnetic charging cable are free from dirt or corrosion.
3. Regularly clean the back of the watch and the metal contacts on the magnetic charging cable with a clean flannel to ensure full contact and normal charging functionality.
4. This product does not include a power adapter. To ensure safety and protect property, use a computer USB interface or a power adapter with an output of no more than 5V/1A for charging. Always purchase high-quality power adapters through reliable channels to avoid risks such as overheating or fire.

App Connectivity

1. To install the app, scan the QR code or visit the APP Store or Google Play and search for "FitCloudPro".
2. Follow the instructions to download and install the app.

Note: The app requires Android 8.0 or higher, or iOS 12.0 or higher. It is also necessary to have wireless hardware version 4.0 or above to ensure full compatibility.



3. Initial App Installation and Setup:

3.1 Install and open the APP for the first time by following the prompts to grant the necessary permissions.



3.2 For iPhone users, the initial mobile phone APP connection will prompt a Wireless pairing request.

3.3 Upon pairing, the watch can receive notification alerts from the iOS system for incoming calls, text messages, and more.

4. Device Binding:

4.1 Open the APP and select "Binding Device" then scan the QR code on the watch or search for "HYPE Watch" to find the device nearby.

4.2 To complete the binding, select the MAC address of your watch, which consists of 12 characters, found under watch settings in the 'About MAC Address'.

4.3 Once the watch displays the Wireless icon or indicates a successful wireless connection, you can use the watch dial to control your mobile phone to make or answer calls, and review the call log directly from your watch.

Notes:

1. When using the Wireless call feature, it is essential to ensure a stable connection between the watch and the mobile phone.

2. In case the connection has been lost, please pull down the main interface on your watch. If the phone icon turns blue, this indicates that the connection has been successfully re-established. Refer to the illustration on the right for further guidance.

Button Guide

1. Activating the Screen: Press the function/back button or lift your hand to wake up the screen.

2. Navigating the Interface:

A. Swipe up to access the notifications bar.

B. Swipe down to enter the control center.

C. Swipe square to enter the music playback interface.

D. Swipe right to enable split screen mode.

Disclaimer

This application is not a medical device. The data obtained during the use of this app is intended for reference purposes only and must not be used for clinical diagnosis, medical research, or any form of treatment.

Specifications

Battery Capacity	400mAh/3.8V (Watch), 35mAh/3.7V (Earbuds)
Battery Type	Lithium-ion polymer battery
Resolution	360×360 IPS
Size	1.52"
Chipset Smart Watch	Bluetrum 8959T5
System Compatibility	Android 5.0 and above, iOS 10.0 and above
Watch Speaker	0916 AAC 8Ω/0.7W speaker ×1
Earbud Speaker	Ø6mm /F6L2× 16
Bluetooth Version	V5.0
App Name	FitCloudPro
Watch Bluetooth Name	HYPE Watch
Earbud Bluetooth Name	HYPE TWS
Recharge Time	4h
Standard	IP67
Calories	Supported
Camera Remote-Control	Supported
Bluetooth Call	Supported
Bluetooth Music Player	Supported
Time Sync	Supported
Call History	Supported
Anti-Lost	Supported
Redial	Supported
Sleep Monitor	Supported
Steps	Supported
Heart Rate	Supported
Bluetooth Headset	Supported
Blood Pressure	Supported
Alarm	Supported
Siri	Supported
APP Supported Languages	Arabic, Bulgarian, Chinese, Czech, Danish, Dutch, English, Finnish, French, German, Hungarian, Italian, Japanese, Korean, Norwegian, Polish, Portuguese, Romanian, Russian, Spanish, Swedish, Ukrainian
Size	Ø50mm×14mm
Weight	68g
Operating Temperature	0°C to 40°C

Watch Functions

1. Dial Replacement

1.1 Long press the main page for 3 seconds to navigate to the watch dial replacement page.

1.2 Select and download the replacement dial from the page.

2. Control Center

Access: Swipe down to enter the Control Center.

2.1 Do Not Disturb Mode: Activate to silence notifications and calls.

2.2 Power Saving Mode: Enable to extend battery life.

2.3 Bright Screen Adjustment: Adjust screen brightness to suit your viewing preferences.

2.4 Settings: Access additional settings.

2.5 Find Phone: Activate to locate your connected phone.

2.6 System Information: View detailed information about the watch's system.

2.7 Vibration & Ringtone Setting: Customize vibration intensity and ringtone sounds.

2.8 Wireless Call & Audio Setting: Manage settings for wireless calls and audio.

3. Do Not Disturb Mode: Navigate to the Control Centre and tap the Do Not Disturb icon to activate this mode.

4. Screen Brightness Adjustment: Scroll down to the Controls, then tap the Brightness Adjustment icon to modify the device's brightness settings.

5. Settings: Access additional functions by scrolling to the Controls and tapping the Settings icon.

6. Find My Phone: In the Control Centre, select the "Find my phone" icon; your phone will vibrate to signal its location.

7. Voice Assistant: Activate the voice assistant by pressing the function/return button. For voice commands, tap the button, or for longer commands, hold the button for 3 seconds.

8. Sports Data: Access the sports data page by pressing the function/return button. Here, you can view and record the steps taken, calories burned, and distance traveled.

9. Messages: To view your messages, slide up to the message bar.

10. Heart Rate Monitoring: Press the Function/Return button to activate the heart rate monitoring feature. Tap once to start the measurement and display the data.

11. Dialing Function: To make a call, slide to the right on the standby interface to access the split screen, and then tap the phone icon to open the dialing interface. This function requires a connection to audio Bluetooth. Once in the dialing interface, enter the phone number and make your call as needed.

12. Sport Mode: Press the Function/Return button to access the sport mode. Here, you can select your favorite sport and view related data.

13. Weather: Press the Function/Return button to open the weather function. Click to view the current weather conditions.

14. Music Control: Press the Function/Return button to access music controls. Click to adjust volume, start, or stop playback of the song.

15. Blood Pressure Monitoring: Press the Function/Return button to access blood pressure monitoring. Click to begin measurement.

Note: This data is for reference only and should not be used for medical diagnosis.

16. Blood Oxygen Monitoring: Press the Function/Return button to access blood oxygen monitoring. Click to begin measurement.

Additional Features

Sleep Monitoring: Tracks sleep patterns and quality.

Chronograph: Measures and records time intervals.

Timer: Allows setting timers for various activities.

Alarm Clock: Enables setting multiple alarms.

Sedentary Reminder: Alerts to encourage movement after periods of inactivity.

Drinking Reminder: Reminds to stay hydrated at regular intervals.

Shake to Take a Picture: Shake the device to remotely capture photos.

Female Physiological Period Tracking: Monitors menstrual cycle (accessible via the app).

Precautions

1. Why is it necessary to wear a smartwatch tightly when measuring heart rate? Smartwatches calculate heart rate using the principle of light reflection. The light must pass through the skin and reflect back to the sensor. If the watch is worn loosely, ambient light can interfere with this process and reduce measurement accuracy.

2. Wearing the smartwatch during hot baths

It is advised not to wear the smartwatch while taking hot baths. The steam generated can penetrate the watch casing through small gaps due to its molecular size. As the temperature drops, this steam condenses into water, potentially damaging the internal circuits.

3. Wireless connectivity

Ensure that both your smartphone and smartwatch are turned on to establish a wireless connection. When performing a wireless search, avoid connecting the smartwatch to another account and keep the smartwatch and mobile phone as close as possible to each other to facilitate a stable connection.

4. Mobile Phone Software Management

If you have installed other applications such as a mobile phone manager, ensure you enable message push notifications and background operations in your smartphone settings to maintain normal functionality of the app linked to your smartwatch.

5. Oximetry Test Instructions

To ensure the accuracy of the test data, remain relaxed and stationary during the oximetry test. Ensure that the smartwatch is level with your heart. Refrain from talking during the test.

Note: This function is intended to provide data for observing changes in blood oxygen levels before and after physical activity and is NOT meant as an alternative to medical test results.

Pairing Earbuds with Phone

A. Initial Pairing

1. Remove the headset from the watch host and listen for the boot tone.
2. Open your mobile phone's Bluetooth settings and search for the corresponding Wireless name "HYPE TWS" for the Wireless connection.
3. If "HYPE TWS" is displayed and connected on your phone, the pairing has been successful.

B. Automatic Reconnection

Removing the headset from the main body of the watch will automatically power it on and initiate pairing with the previously connected device.

C. Reconnecting

1. If the headset disconnects from the mobile phone during use, you must manually reconnect it.
2. In your phone's Bluetooth settings, if a previous model appears, please clear this setting first, then reconnect to "HYPE TWS".

D. Pairing Single Earbud

If only one earbud is producing sound, you need to pair the headset earbuds to each other again.

Pairing Earbuds with Each Other

A. Powering Off

Press and hold both headphones for 6 seconds to turn off the power.

B. Initiating Pairing

1. Simultaneously press and hold both headphones to switch them on.
2. Continue to hold until the indicator lights start flashing alternately.
3. Ensure you do not touch the sensor areas of the headphones during this process.
4. Press both headphones simultaneously seven times, and then release.
5. Both headphones will automatically power off, indicating that they are ready to pair.

C. Completing the Pairing

1. Place both headphones back into the watch compartment and remove them at the same time.
2. Upon doing so, only one headphone light should remain on after switching on the watch.
3. This indicates that only one of the headphones is active, confirming successful pairing.

Earbud Instructions for Use



A. Touch Sensor Area

The middle surface of the earbud features a touch-sensitive area used to control phone call operations (answer/hang up), volume adjustments (up/down), and interactions with the AI voice assistant.

B. Managing Incoming Calls

1. When the earbud detects an incoming call while housed within the watch, it will automatically connect upon removal.
2. If the earbud has been inside the watch for an extended period, you will need to manually answer the call by double-clicking the button.
3. To hang up, double-click the button again.
4. The earbud will power off automatically once returned to the watch during the call.
5. If the call is not ended by earbuds, the call will automatically be transferred to the mobile phone to manage.

C. Music Operation

1. To pause or play music, double-click.
2. Hold the button for two seconds to skip to the previous or next song.
3. For volume adjustment, triple-click for increasing or decreasing the volume.

4. AI Voice Assistant

1. Once the earbud is connected in Wireless mode, you can activate Siri on iPhones and the voice assistant on Android devices by clicking the touch key four times.
2. The voice assistant function allows you to make calls, check the weather, navigate maps, and access other functions through voice commands.

Note: The voice assistant must be enabled in the mobile phone's standby interface or main interface to function effectively.

Earbud Usage Precautions

- 1.** The results of this product are for reference only and are NOT intended for medical use. Please follow your doctor's instructions and do not rely solely on the measurement results for self-diagnosis and treatment.
- 2.** Be careful when enabling the factory reset function as it may result in the loss of app content, settings, and watch history data.
- 3.** When the power of the watch is below 20 %, the watch can still be used normally. However, if the earphones are placed back into the charging compartment, they will not charge if the earphone light does not illuminate. In this case, you will need to manually turn off the headphones or charge the watch.
- 4.** After using the earbud, please clean any oil and water stains from the charging port and remove any debris from the earbud compartment of the watch promptly.

Attention



Troubleshooting

1. App Connection and Function Stability

- a.** If the app is not connected or some functions are unstable, ensure that the watch is adequately charged.
- b.** Verify that specific functions are enabled and watch is connected to App (refer to App Connectivity section).

2. Mobile Phone and Watch Settings

- a.** Ensure the Wireless feature on your mobile phone is turned on.
- b.** Check that all necessary APP permissions are enabled in your mobile phone settings.

3. Avoiding Device Conflicts

- a.** If multiple devices are nearby, it is possible that others may connect to your phone by mistake or that the phone is already connected to another device.
- b.** In such cases, disconnect any unwanted devices from your phone.
- c.** For Apple mobile phones, locate the unwanted device under Wireless settings and select "Ignore this device."

4. Limiting Wireless Connections

- a.** If too many Wireless devices are connected or have been connected to your mobile phone, it is advisable to limit the number of devices.
- b.** Ensure that no more than 10 Wireless devices are connected or paired with your phone.

5. Distance and Obstacles

Ensure that the distance between the mobile phone and the watch is not too great and that there are no significant obstacles interfering with the connection.

6. App Permissions

- a.** Open permissions for storage, phone, location information, camera, etc., on your mobile phone to ensure full functionality.
- b.** Due to variations across different brands, you may need to adjust these permissions according to the specific prompts during app installation.
- c.** Failure to set these permissions appropriately may result in operational errors or restricted app functionality.

7. Permission Adjustments

If an error occurs or app functions are blocked due to permission issues, please adjust the app permissions according to your mobile phone's brand and model.

8. Software Updates

Regularly check and update the app or watch software to the latest version to ensure optimal performance and compatibility.

9. Function Restrictions

Information, weather, time, and other functions cannot be modified or pushed if not configured correctly in the app.

10. Battery Level

Ensure the watch is charged if these functions appear inactive or unstable.

11. Activating Notifications

To enable message reminders and weather updates, open the app and select the appropriate settings for message push and weather notifications.

12. Wireless Connectivity

Confirm that the wireless connection of your mobile phone is active. Both your phone and watch should be connected properly to ensure seamless functionality.

13. Data Synchronization

Weather data is regularly updated in the background by the app, synchronized from the server to your watch. Ensure your network connection is stable.

14. Server Updates

Updates and upgrades to the data server may lead to temporary synchronization issues. Please be patient and wait for the completion of the upgrade process.

15. App Functionality

The app primarily serves to record and store data. Note that some functions are fixed and cannot be modified or directly manipulated.

16. Time Synchronization

The time displayed on the watch is synchronized through your mobile phone connection. You can also manually set the time on the watch if needed.

17. Battery Level

If the watch is lagging, it may be due to a low battery. Please charge the watch.

18. Memory Usage

High memory usage can also cause lagging. Restart both your mobile phone and watch to clear memory and improve performance.

19. Environmental Factors

If you are experiencing issues in environments with extreme temperatures or humidity, consider changing your location to see if performance improves.

20. Call Synchronization

If incoming calls are not being synchronized to the watch, ensure that the incoming call reminder function is enabled in the app settings.

21. Connection Check

Verify that the watch is successfully connected to the mobile phone to ensure functionality.

22. Music Mode

For issues related to using the watch with your mobile phone's music functions, select the "Mobile Phone Music" mode as detailed in the app connection instructions of this manual.

FCC Compliance Statement

Notice: This equipment has been tested and found compliant with the limits for a Class B digital device, according to part 15 of the FCC Rules. These standards are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used according to the instructions, it may cause harmful interference to radio communications. This equipment can cause interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference through one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**