

PORODO



Porodo 10000mAh Digital MagSafe Power and Stand

SKU: PD-PBFCH050




Table of Contents

Schematic View	2
Specifications	2
Package Contents	3
Product Overview	3
Charging the Product	3
Indicator Guide	3
Charging Other Devices	4
Precautions	4
Statement	5
Warranty	6
Contact Us	6

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Schematic View




Specifications

Product Name	Porodo 10000mAh Digital MagSafe Power and Stand
SKU	PD-PBFCH050
Battery Capacity	10000mAh
USB-C Input	5V/3A, 9V/2A, 18W
USB-C Output	5V/3A, 9V/2.22A, 12V/1.67A, 20W
USB-A Output	5V/3A, 9V/2A, 12V/1.5A, 5V/4.5A (SCP) 22.5W
SCP	9V/2A, 12V/1.5A, 18W
Wireless Output	5W, 7.5W, 10W, 15W
Product Size	21×68×103mm

K Package Contents



Portable power bank and stand



USB to Type-C charging cable

K Product Overview

This product is a portable charging device capable of providing wireless and wired charging for multiple devices such as mobile phones, tablets, game consoles, and more. It features a battery indicator light and is designed to be compact and portable. The device includes built-in FOD (Foreign Object Detection) and several safety features such as protection from overcharging, over-discharging, and overheating, ensuring safe and efficient charging.

K Charging the Product

1. Use a power adapter to connect the device to a power outlet for charging.
2. Plug the Type-C charging cable into the input port of your device and connect the other end to the power supply.
3. The lights will flash to indicate that charging has begun.
4. Once fully charged, all four lights will remain on.

K Indicator Guide

The device features four battery indicator lights, each representing 25% of the battery level. When one light is on, it indicates 25-49% battery remaining. Two lights indicate 50-74% battery, and three lights indicate 75-99% remaining. When all four lights are on, the device has 100-100% battery.

Charging Other Devices

A. Wireless Charging

1. Ensure the wireless output power is compatible with the requirements of your wireless-enabled device.
2. Position the device on the wireless charging area to start charging.

B. Wired Charging

1. Verify that the charging voltage of the device matches the output voltage of this product.
2. Connect the original charging cable to the device and plug the other end into the output port of this product.
3. Charging will begin automatically, and the digital display will stay on throughout the process.

Precautions

Please review all instructions and warnings prior to using this product to avoid damage or risks to personal safety.

1. Ensure the charging area on the back of the mobile phone is free from any metallic objects such as metal sheets, rings, or metal cases.
2. If you experience intermittent charging or excessive heating during charging, it may be due to misalignment of the phone's wireless charging coil. Ensure there are no metal obstructions in the protective sleeve and realign the phone properly on the charger.
3. This product is equipped with an over-current protection feature that will reduce output power or halt charging to maintain safety if used incorrectly. Verify the proper functioning of this feature regularly.
4. Avoid placing the product in environments with water, open flames, extremely high or low temperatures (beyond 50°C or below -20°C).
5. To clean the product, use a soft, dry cloth. Avoid using water, detergents, or abrasive cleaning solutions.

6. Do not attempt to disassemble the product on your own. Improper use or disassembly may shorten its lifespan or cause damage. The manufacturer and warranty provider are not responsible for any resulting damage.
7. Please note that the conversion rate of the mobile power supply affects the battery capacity, which may differ from the rated rechargeable capacity.
8. To prolong the battery life, it is recommended to charge the power bank regularly, at least every five months.
9. Improper use of the product may result in damage to the device or pose a safety risk to both people and property.
10. Only qualified professionals should attempt to service or disassemble this product.
11. Avoid connecting devices that exceed the current output of the power bank, as this will trigger circuit protection and prevent output.
12. Prevent physical impacts such as dropping, trampling, or squeezing the product, as these actions may result in malfunction

Component	Toxic Materials					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr VI)	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
PCB	×	○	○	○	○	○
electrode	○	○	○	○	○	○
Battery	×	○	○	○	○	○
Shell	○	○	○	○	○	○

Statement

This product follows the customization of SJ/T 11364, indicating that the levels of toxic and harmful substances in all homogeneous materials used in the components meet the standards specified in GB/T 26572.10. However, for certain auxiliary materials, the levels of toxic and harmful substances in at least one homogeneous material exceed the limits specified in GB/T 26572. This product complies with the EU RoHS 2.0 Directive (65/2011/EU).

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at porodo.net/warranty and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**