

PORODO
LIFESTYLE



Porodo Lifestyle
Water Dispenser and Ice Maker

SKU: PD-LFST085

Table of Contents

Important Safety Instructions	2
Schematic View	3
Control Panel	4
Operating Instructions	4
Specifications	5
Schematic View	6
Troubleshooting	6
Disposal	7
Warranty	8
Contact Us	8



Important Safety Instructions

When using electrical appliances, basic safety precautions should be followed to reduce the risk of fire, electric shock, and injury to persons or property. Please read all instructions before using any appliance.


- 1.** Avoid contact between hot water and bare skin. Keep flammable materials such as furniture, bedding, pillows, clothes, and paper away from the back of the unit.
- 2.** Do not operate this or any other appliance with a damaged power cord. Ensure no other appliance is plugged into the same outlet and that the plug is fully inserted.
- 3.** Keep the power cord away from carpeting, heat insulation, and high-traffic areas. Never cover the cord or submerge it in water.
- 4.** Avoid using an extension cord, as it may overheat and pose a fire risk.
- 5.** Exercise caution and supervise children when the appliance is in use.
- 6.** Do not use the water dispenser outdoors. Keep it out of direct sunlight and ensure there is at least 4 inches (10 cm) of space between the back of the unit and the wall. Maintain a minimum of 2 inches (5 cm) of clearance on each side.
- 7.** Only use this product to dispense water. Do not use it for any other liquids.
- 8.** Place the appliance on an even, flat surface to avoid instability hazards.
- 9.** If the power cord is damaged, it must be replaced by an authorized service agent or a qualified professional to avoid hazards.
- 10.** Position the water cooler so the plug is always accessible.
- 11.** Unplug the appliance when not in use.
- 12.** Remove the power plug or disconnect from the main power source before servicing the appliance.
- 13.** Children and pets should be supervised when the device is operational.
- 14.** Keep this manual for future reference.

K Schematic View

1. Water Guard
2. Top Cover
3. Control Panel
4. Hot Faucet
5. Ambient Faucet
6. Cold Faucet
7. Water Collecting Box
8. Ice Storage
9. Air Inlet
10. Power Cord
11. Ice Storage Sewage Outlet
12. Outfall
13. Air Outlet



Control Panel



Operating Instructions

Standby

When the machine is powered on, the buzzer will beep once, and the power indicator will light up. The machine will then enter standby mode.

Hot Water Function

To activate the hot water function, press the heating touch. The buzzer will beep, and the hot water indicator will start flashing. Once the water reaches the desired temperature, the indicator will stay on. To turn off the hot water function, press the heating touch again. The indicator will turn off, and the hot water function will stop.

Cold Water Function

To activate the cold water function, press the cooling touch. The buzzer will beep, and the cold water indicator will start flashing. Once the water reaches the desired temperature, the indicator will stay on. To turn off the cold water function, press the cooling touch again. The indicator will turn off, and the cold water function will stop.


Ice-Making Function

To activate the ice-making function, press the ice-making touch. The buzzer will beep once, and the ice-making indicator will start flashing, signaling that the function is on. Each ice-making cycle takes approximately 10 minutes. When the indicator stays on continuously, it means the refrigerator is full, and ice-making is paused. To resume, remove the ice cubes from the box, and the machine will restart the ice-making process. To turn off the ice-making function, press the ice-making touch again. The indicator will turn off, and the function will stop.

Specifications

Rated Voltage	220-240V
Rated Frequency	50-60Hz
Cooling Power	100W
Heating Power	500W
Cold Water Tank Capacity	2.8L
Hot Water Tank Capacity	1.1L
Cooling Capacity	2.0L/h
Heating Capacity	5.0L/h
Ice Storage Capacity	1.1KG
Hot Water Temperature	90°C to 95°C
Cold Water Temperature	5°C to 10°C
Ice Quantity per Cycle	9 pcs
Tank Material	Stainless Steel
Power Cord	UK 3-Pin Plug
Net Weight	18KG
Dimensions	310×355×1052mm

Schematic View



Troubleshooting

Problem	Possible Cause	Solution
The fault indicator is on, and the hot water indicator flashes quickly.	Hot water temperature sensor short circuit or open circuit.	Contact sales service.
The fault indicator is on, and the cold water indicator flashes quickly.	Cold water temperature sensor short circuit or open circuit.	Contact sales service.
The fault indicator is on, and the ice-making indicator flashes quickly.	Ambient temperature sensor short circuit or open circuit.	Contact sales service.
The fault indicator is on; the ice box is stuck and cannot be turned over.	The ice evaporator position is too low.	Adjust the position upwards.

The ice cubes are connected together.	Ice-making cycle time is too long.	Turn on the machine after 15 minutes of shutdown.
The warm water temperature is too high.	Leaking bucket, water level is too high.	Replace the bucket.
The ice-making process is normal, but no ice is formed.	Ambient temperature or water temperature is too high.	Make ice only when the ambient temperature is below 32°C.
The fault indicator flashes quickly, and the ice-making indicator goes out.	Ice-making lacks water.	Replace the bucket with water.
No ice and no cooling water.	Leaking or clogged refrigeration system.	Contact sales service.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**