



# Powerology


**IonFusion Hot and Cold Hair Dryer**

SKU: PXMLV10GR

# Table of Contents

Product Overview	2
Instructions for Use	2
Specifications	3
Product Features	4
Maintenance and Care	4
Attention	4
Symbol Explanations	5
Warning	5
Material Contents	6
Disposal	7
Warranty	8
Contact Us	8

# D Product Overview



## Important:

Keep out of reach of children to prevent access to the air intake.

We recommend cleaning the air intake filter with a brush once a week.

**1. Fast drying nozzle**

**2. Air outlet**

**3. Display panel**

**4. Wind speed / power switch**

**5. Temperature / function**

**6. Handle**

**7. Air inlet**

**8. Power cable**



Do not use this product near a bathtub, shower, sink, or any other water-retaining objects.

# D Instructions for Use

## A. Power Switch / Speed Switch:

1. Press and hold for 2 seconds to turn the product on or off.
2. Press the wind velocity switch to adjust the wind speed settings.

## B. Function Key Introduction:

1. Press the temperature key to adjust the temperature settings.
2. Press and hold the function key for 2 seconds when the hair dryer is inactive. This will initiate the auto-cleaning mode, which will automatically stop after 10 seconds.

**Wind Velocity:** Press briefly to switch between high or low speed.



**Temperature:** Press briefly to adjust the temperature settings.



**Power On/Off:** Press and hold for 2 seconds to turn the device on or off.

**Cold & Hot Cycle Mode:** After powering on, press and hold for 2 seconds to switch between cold and hot cycle mode.

## Specifications

Model	PXMLV10
Rated Voltage	220-240V
Rated Frequency	50Hz
Rated Power	1400W
Wind Speed	65m/s
Motor Speed	110000RPM
Power Cord	UK 3-Pin
Cable Length	1.8m
Product Weight	315g
Product Size	79 x 60 x 250mm
Executive Standards	GB 4343.1-2018, GB 4706.15-2008, GB 4706.1-2005, GB 17625.1-2022

## **Product Features**

### **1. Temperature Settings:**

The hair dryer features three distinct temperature modes: Hot Wind, Warm Wind, and Cold Wind. These settings cater to different drying requirements for various hair types.

### **2. Plasma Hair Care Technology:**

**2.1** The hair dryer incorporates plasma hair care technology that effectively reduces static electricity in hair.

**2.2** It also helps tighten hair cuticles, minimize frizz, and promote smooth, long-lasting, and beautiful hair.

**2.3** Plasma is generated in both hot and cold air modes for enhanced care.

## **Maintenance and Care**

**1.** Ensure that the power/speed switch is turned off and the product is unplugged before cleaning.

**2.** Use a towel, cotton swab, or toothbrush to clean the air intake and outlet attachments regularly.

**3.** Do not press or rub the air intake and outflow with nails or any sharp objects to prevent product damage.

**4.** Avoid using alcohol, nail polish remover, or detergent to clean the product, as they may cause malfunction, breakage, or discoloration.

## **Attention**

To ensure safe operation and prevent potential hazards such as malfunction, electric shock, injury, fire, or damage to equipment and property, please adhere to the following precautions.

## **Symbol Explanations**

**Warning:** This symbol indicates a potentially life-threatening hazard that could result in severe injury or death.

**Caution:** This symbol indicates a risk of minor injury or damage.

**Prohibited Action:** This icon serves as a reminder to avoid prohibited actions that may cause harm or damage.

**Important Reminder:** This icon emphasizes necessary steps for the safe operation of the product. Always follow these instructions to ensure optimal safety.

## **Warning**

### **Power Cable and Plug**

Do not use the product if the power cord or plug is damaged or overheated, as this may result in burns, electric shock, or fire due to a short circuit.

Ensure the power plug is securely connected to the socket. A loose plug may cause a short circuit, leading to burns, electric shock, or fire.

Never attempt to unplug the power cord with wet hands, as this could result in an electric shock or injury.

Do not use the product if the power cable is knotted or tangled, as this could cause an electric shock or fire due to a short circuit.

Do not bend, twist, pull, or break the power cord. Avoid placing heavy objects on the cord or squeezing it, as this may lead to electric shock or fire due to a short circuit.

When unplugging, do not pull the power cord. Instead, grip the power plug and gently pull it out. Pulling on the cord could lead to disconnection, electric shock, or fire caused by a short circuit.

Ensure the power plug is fully inserted into the socket. Only use the socket, not the power terminal block. A loose or improperly inserted plug can cause a short circuit, leading to electric shock, burns, or fire.

If the power cord is damaged, it must be replaced by a professional from the manufacturer or its authorized service center to avoid any risks.

## Safety Instructions

To prevent electric shock, avoid inserting metal objects into the air outlet.

Do not block the air outlet of the hair dryer to ensure proper ventilation and safe operation.

Before using the product, verify that the voltage on the device matches the local power supply voltage.

Do not use this product on wigs or artificial hair, as this could cause damage to the product or the hair.

Never leave the product powered on without supervision to avoid potential safety risks.

## Material Contents

Part Name	Harmful Material					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr <sup>6+</sup> )	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Motor	×	○	○	○	○	○
Ion Generator	×	○	○	○	○	○
Power Switch	○	○	○	○	○	○
Cables	○	○	○	○	○	○
Hardware Parts	○	○	○	○	○	○
Plastic Materials	○	○	○	○	○	○
Packaging Materials	○	○	○	○	○	○
Electronic Components	×	○	○	○	○	○
Power Cable Plug	×	○	○	○	○	○

## Compliance Statement

This document has been developed in accordance with SJ/T11364. O: The content of the hazardous substance in all homogeneous materials of this part is below the limit requirements specified in GB/T26572.

X: The content of the toxic and hazardous substance in at least one homogeneous material of the part exceeds the limit requirements stipulated in GB/T26572.

## Important Notes:

The "hazardous substances" listed in this table do not pose a threat to humans or the environment under normal usage conditions.

The "hazardous substances" and components in this table provide consumers and recyclers with important information about the relevant compounds, helping to ensure proper disposal of the products when they are discarded.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



## **Warranty**

Products that you buy directly from our **Powerology** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **Powerology** website or store. If **Powerology** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website **powerology.me/warranty** and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:  
**powerology.me/warranty**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at: **hey@powerology.me**

Website: **powerology.me**

Instagram: **powerology\_official**

Facebook: **powerology.ME**