## **PORODO**



# **Porodo**

SWAY 60000mAh Power Bank

SKU:PDPBFCH092BK


# Table of Contents

Product Overview	2
Schematic View	2
Button Functions	2
Specifications	3
Charging Operations	3
Product Hazardous Substances	4
Important Notices	4
Disposal	5
Warranty	6
Contact Us	6

## Product Overview

The Porodo SWAY 60000mAh Power Bank offers powerful and portable charging with a built-in LED light, making it ideal for on-the-go power needs. It features two USB-A and two USB-C ports for versatile device charging, supporting fast charging with a 100W power output and 22.5W Quick Charge. The power bank is designed with an easy-to-carry handle, and the LED light provides additional convenience, making it suitable for both charging and illumination in various situations. It ensures reliable and efficient charging for multiple devices while offering a sleek and durable design.

#### Schematic View



#### **Button Functions**

- 1. Power Button:
- 1.1. Power-Off Mode: A short press displays the battery level.

- 1.2. Charging Mode: A short press turns off the device.
- **1.3.** Power-On Mode: A long press activates small current mode, and a single press activates normal current mode.
- 2. LED Button:
- **2.1.** Press for 2 Seconds: Turns on the flashlight at low brightness; a short press switches to high brightness, and another press cycles through the lighting modes.
- 2.2. In High Brightness Mode: A long press for 2 seconds switches to SOS mode.
- **2.3.** In SOS Mode: A long press turns off the SOS function, and the flashlight continues at the previous brightness level.

## **Specifications**

Model	PDPBFCH092BK
Battery Power	10000mAh/22.2V 222Wh
Battery Capacity	10000mAh×6
USB-C1/C2 Input	5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/5A, 100W Max
USB-C1/C2 Output	5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/5A, 100W Max
USB-A1/A2 Output	5V/3A, 9V/2A, 12V/1.5A, 10V/2.25A, 22.5W Max
Product Size	66.8 × 87.2 × 169.6mm

#### **Charging Operations**

- 1. Select the appropriate charging cable and connect one end to the input port of the power bank.
- 2. Connect the other end to a charger or computer. The LED display will begin flashing, indicating that the power bank is charging.
- **3.** Ensure the charging cable is compatible with the power bank's output voltage.

**4.** Connect the appropriate charging cable from the device to the power bank. The device will automatically begin charging, and the LED display will show the current battery level.

#### Product Hazardous Substances

	Hazardous Substances						
Part Name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr6+)	PolyBrominated Biphenyls (PBB)	PolyBrominated Diphenyl Ethers (PBDE)	
Circuit Board	×	0	0	0	0	0	
Five Metal Parts	×	0	0	0	0	0	
Plastic Parts	0	0	0	0	0	0	
Battery	0	0	0	0	0	0	
Accessories	0	0	0	0	0	0	

#### Note:

- 1. This table is compiled according to the SJ/T 11364-2014 standard.
- 2.  $\bigcirc$  indicates the content of the hazardous substance in the part meets the requirements set by the GB/T 26572 standard.
- **3.** × indicates the content of the hazardous substance in the part exceeds the limits specified in the GB/T 26572 standard.
- **4.** The environmental protection mark with the "O" symbol is only suitable for products in consumer use according to the manual's guidelines.
- **5.** The "x" symbol indicates no alternative technical components available in the current stage of production.

## Important Notices

1. Before using this product, please read the user manual carefully and follow the instructions for proper use.

- 2. Only use accessories and parts recommended for this product. Do not install or remove components while the product is powered on to avoid any potential damage.
- **3.** Do not use the product in environments where the temperature exceeds 55°C or is below -10°C to avoid damage.
- 4. When charging the battery, make sure it is connected to a suitable power source. Avoid using damaged or swollen batteries, and only use batteries recommended by the manufacturer.
- **5.** If the product experiences abnormal functioning or leakage, please stop use immediately and contact the manufacturer for further assistance.
- **6.** For the longest lifespan, ensure the product is used within the recommended operating conditions, including charging and storage, as specified in the manual.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.





Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **https://www.porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

https://www.porodo.net/warranty

# Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: https://www.porodo.net/ Service Support: support@porodo.net

Instagram: porodo