

PORODO



Porodo

**10000mAh
MINI POWER BANK**

SKU: PDPBFCH096GY

Table of Contents

Product Overview	2
Specifications	2
Product Design	3
Package Contents	3
Battery Level Indicator	3
Recharging the Power Bank	3
Charging Electronic Devices	4
Declaration of Toxic and Hazardous Substances	4
Maintenance and Care	5
Safety Precautions	5
FCC Statement	6
Disposal	7
Warranty	7
Contact Us	7

Product Overview

The Porodo 10000mAh Mini Power Bank is a compact and efficient solution for on-the-go charging. It features fast charging capabilities with PD 35W and QC 22.5W, ensuring quick power-ups for your devices. The real-time display offers a clear and convenient view of the battery level and charging status. With simultaneous charging support, you can power up multiple devices at once without any hassle. Built-in safeguards protect your devices from overcharging and overheating, providing peace of mind while you charge. This power bank is a perfect travel companion, offering portability and reliable performance.

Specifications

Battery Capacity	10000mAh
Type-C Input	5V/3A, 9V/2.22A, 12V/1.67A, 12V/1.33A, 20V/1A, 20W
Type-C Output	5V/3A, 9V/3A, 10V/2.25A, 12V/2.9A, 15V/2.33A, 20V/1.75A, 35W Max
USB-A Output	5V/3A, 9V/2A, 10V/2.25A, 12V/1.5A, 22.5W Max
Product Size	38 x50×86.5mm
Product Weight	205g
Model Number	PDPBFCH096

Product Design



Package Contents


Power Bank x1

Type-C Charging Cable x1


Battery Level Indicator

Press the power switch, and check the LED digital display screen to display the accurate percentage of remaining power.

Recharging the Power Bank



Charging Electronic Devices



Declaration of Toxic and Hazardous

Component Name	Declaration of Toxic and Hazardous Substances					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent (Cr(VI))	Polybrominated Biphenyl (PBB)	Polybrominated Diphenyl Ether (PBDE)
PCB	X	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Casing	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Battery Core	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Hardware	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

This form is compiled in accordance with SJ/T 11364.

O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.

X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

Note: Reasons for using materials with “X” in this power bank: No alternative technologies or components are available at this stage.

Maintenance and Care

1. Regular use keeps the electrons of the cell in optimal motion.
2. If the power bank is not used frequently, charge the Power Bank to 50% to maintain battery life.
3. If the power bank is not used for extended periods, charge and discharge the Power Bank every three months.
4. Always handle digital products safely and ensure they are used in safe environments. Pay attention to electrical safety.

Safety Precautions

1. Avoid exposing the product to high temperatures, moisture, or direct sunlight.
 - a. Operating Temperature: Charging: 0°C–45°C
 - b. Discharging: -10°C–60°C
 - c. Storing: -20°C–60°C
2. Do not expose the product to fire or submerge it in water. Clean with a dry cloth to prevent malfunctions.
3. Do not cover the product during normal use; provide enough airflow to avoid overheating.
4. Never leave the product unattended while charging.
5. Do not attempt to disassemble the product. No spare parts for disassembly are included.
6. Do not drop, shock, knock, crush, or squeeze the product.
7. Avoid short-circuiting the product to prevent fire hazards.
8. Keep the product out of children's reach.
9. Make sure that the charger output matches the rated input of the product to avoid damage.
10. Overcharging may lead to smoke and fire hazards. Always use a charger with the correct voltage rating.
11. Use a 3C-certified charger from a reputable manufacturer to recharge the power bank.

12. Disconnect the charger once the product is fully charged.
13. Stop using the product immediately if any abnormalities (e.g., heat, deformation, discoloration, leakage) are observed.
14. In case of skin contact with leaked battery fluid, rinse immediately with clean water and seek medical advice.
15. Properly dispose of the power bank when it is no longer usable.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference; and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for assistance.

RF warning statement: The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**