

**Green Lion**

**Heater Power**

**Fan & Heater with Remote Control**

SKU: GNHTPW1800BK

Model No: GHT1800

## Table of Contents

Product Overview	2
Specifications	2
Package Contents	3
Product Diagram and Features	3
Remote Control Features	4
Extention Cable	4
How to Operate	4
How to Set the Timer	5
How to Control the Air Flow	5
Safety Precautions	6
Heater Safety Guidelines	7
Post-Operation Guidelines	8
Maintenance	8
Important Notes	9
Battery Installation Guide	9
Repair or Replacement	10
Disposal	11
Warranty	11
Contact Us	11

## Product Overview

The Green Lion Heater Power is a versatile 2-in-1 device designed to keep you comfortable throughout the year. Featuring both fan and heater functions, it offers a convenient solution for temperature control in any space. With the added benefit of remote control, you can easily adjust settings from a distance, making it perfect for homes, offices, or any indoor setting. Whether you need a cooling breeze on a hot day or a warm atmosphere during colder months, the Green Lion Heater Power provides efficient, reliable, and user-friendly performance.


## Specifications

Model No.	GHT1800
Material	Fireproof ABS, PP, PBT
Rated Voltage	220-240V
Rated Frequency	50/60Hz
Rated Power	1800W
Wind Speed	High: 2.75m/s, Low: 1.64m/s, Fan:2.46m/s
Heating Coverage	18m <sup>2</sup>
Timer Function	2H, 4H, 8H
Mode	3 Settings (High Heat / Low Heat / Fan)
Filter	Detachable Filter Screen
Oscillation Angle	80° (Left-Right), 45° (Up-Down)
Noise Level	42.9 dB
Power Plug	3-Pin UK Plug
Gross Weight	3.7KG
Product Dimension	202*203*530mm


## Package Contents

- Ceramic Heater
- Remote Control

## Product Diagram and Features



1. Indicator Lights & Control Panel
2. Air Outlet
3. Turntable Base
4. Handle
5. Dust Screen/Air Inlet
6. Main Switch
7. Remote Control



## Remote Control Features

1. Heat Settings: Choose from 2 heat settings to adjust the warmth level according to your preference.
2. Fan Settings: Use the fan setting to circulate air without heating, offering a cooling option during warmer months or for air circulation.
3. Timer Function: Set the timer to automatically turn off the heater after 4, 2, or 8 hours, ensuring efficient energy use and peace of mind.

## Extention Cable

Operating up to a distance of 30 meters (100 feet) without any noticeable loss of heating efficiency, this heater ensures consistent warmth over a wide area, making it suitable for larger rooms or open spaces.


## How to Operate

1. Powering On:
  - a. Press the "ON/OFF" switch located at the base of the heater to enter standby mode.
  - b. To activate the heater, press the "POWER" button either on the unit's control panel or the remote control. A click sound will confirm activation.
2. Heat Settings:
  - a. Upon turning the heater on, it will initially operate at high heat. The indicator light on the unit will illuminate to signify this setting.
  - b. To adjust the heat level, press the "MODE" button on the remote control to toggle between High and Low heat settings. The corresponding light on the unit's control panel will illuminate as follows:
    - Light Red: Low Heat
    - Dark Red: High Heat
    - Blue Light: Fan Mode (no heat)
3. Powering Off:

- a. To turn off the heater, press the "POWER" button again.
- b. The unit will continue to run for a few seconds to dissipate any residual warmth, ensuring efficient operation and the clearance of warm air from the heating elements before shutting down completely.

## How to Set the Timer

### A. On the Heater Unit:

Press  the timer button, on the top of the unit to cycle through the available time settings. A red light will illuminate, indicating the selected time duration:

- 1. Once for 2 hours
- 2. Twice for 4 hours
- 3. Three times for 8 hours



**Note:** You can alternatively use the timer button on the remote control to toggle between the 4 ,2, and 8-hour options.



### B. Automatic Timer Memory:

If the heater is set to turn off based on the timer function, it will remember the last timer setting used. The next time the unit is turned on, it will automatically revert to that same timer duration, providing you with a seamless user experience.

## How to Control the Air Flow

### 1. Oscillation – Moving Left to Right:

a. To activate oscillation, touch and hold the  button on the unit for 2 seconds or touch the  button on the remote control. The heater will begin to oscillate, moving left to right, distributing heat more evenly across the room.

b. To stop oscillation, simply touch and hold the  button on the unit for 2 seconds or touch the  button on the remote control again. The unit will return to a fixed position.

## 2. Oscillation – Swinging Backwards and Forwards:

**a.** To activate the swing function, touch and hold the ⌚ button on the top of the unit for 2 seconds, or touch the ① button on the remote control. The heater will begin to swing back and forth, helping distribute heat over a larger area.

**b.** To stop the swing function, touch and hold the ⌚ button on the unit for 2 seconds, or touch the ① button on the remote control. The unit will return to a stationary position.



## Safety Precautions

**1.** The heater has been designed for heating small and medium spaces. This appliance is intended for indoor household use only.

**2.** Thoroughly read this manual before operating the appliance. This ensures proper usage and safety.

**3.** Retain the manual for future reference, especially if you need guidance or have concerns about the product later.

**4.** The heater is designed for specific uses, as outlined in this manual. Any deviation from the intended use can be hazardous.

**5.** Only use accessories or attachments that are specifically recommended in this manual. The use of unauthorized attachments may increase the risk of injury or malfunction.

**6.** Before using the product, remove it from its packaging and inspect it to ensure it is in good working condition. Never use the appliance if it appears damaged.

**7.** Keep the packaging material, including plastic bags, away from children as they may pose a choking hazard. Never allow children to play with these parts.

**8.** Always follow basic safety precautions to reduce the risk of fire, electric shock, personal injury, and damage. Ensure the heater is placed on a stable surface, away from flammable materials, and plugged into a properly grounded outlet. Never cover the heater, and inspect it regularly for damage. Always supervise the heater when in use and keep it out of reach of children and pets.

## Heater Safety Guidelines

1. Ensure the main circuit voltage matches the heater's required rating before use to avoid damage or malfunction.
2. Place the heater on a flat surface and avoid positioning it directly below an electrical socket to ensure safety and proper airflow.
3. Always make sure that the air intake and outlet are not blocked to prevent overheating and ensure efficient operation.
4. Never cover the heater. Blocking the air vents can cause the device to overheat, leading to potential damage or fire hazards.
5. Do not use the heater in damp areas such as bathrooms, showers, or near swimming pools to avoid electrical hazards.
6. Always unplug the heater when not in use or during operation to minimize fire risks and save energy.
7. If the appliance or cable is damaged, stop using it immediately. Only authorized service personnel should attempt repairs.
8. Keep the heater out of reach of children or individuals with limited physical, sensory, or mental capabilities unless they have received proper supervision or instructions.
9. Keep children under 3 years old away from the heater. Children aged 3-8 may operate it only under supervision and with guidance on safe use. Children between 3 and 8 years should not plug in, adjust, or clean the heater. They may only turn it on or off with instructions on safe handling.
10. Parts of the heater can get very hot. Ensure children and vulnerable individuals are kept away from hot surfaces to prevent burns.
11. Never allow the power cable to hang over the edge of furniture or come into contact with hot surfaces to avoid hazards.
12. Ensure the cable is fully extended before use, as a coiled or tangled cable may cause overheating.
13. Always pull the plug from the socket directly, never by the cable, to avoid damage to the cord or plug.
14. Do not carry the appliance by the power cable.



15. Do not operate with wet hands.
16. Do not leave the appliance unattended when on.
17. Do not use an extension cable unless necessary.
18. Ensure no other high-current appliances are on the same circuit.
19. Unplug the appliance when not in use or before cleaning.
20. Do not use a damaged cable or plug.

## **Post-Operation Guidelines**

1. Do not use a wet cloth or water on any part of the unit, as this may lead to a short circuit or electrical shock, which could pose a serious safety risk.
2. Always keep the unit clean and free from debris. Avoid allowing any objects to enter the ventilation openings, as this could result in an electric shock or damage to the unit's internal components. Additionally, ensure that the unit is switched off at the wall socket before unplugging it for cleaning or when it is not in use.
3. Periodically inspect all inlets and outlets for the accumulation of dust or debris, which could interfere with the unit's proper functioning.
4. Disconnect the unit from the mains when not in use, before moving, or cleaning it.
5. Switch off and remove the plug before leaving the appliance unattended or performing maintenance.
6. Store the appliance in a dry place when not in use, and keep it out of reach of children.

## **Maintenance**

1. Do not dismantle or repair any part of the heater. Only qualified service agents should handle repairs, including replacing the power cable.
2. If the heater malfunctions, stop using it immediately. Contact the manufacturer or an authorized service center for assistance. Avoid attempting repairs yourself.
3. If technical issues occur, turn off the heater right away. Take it to an

authorized service center for professional inspection and repair. Always use original spare parts for repairs.

4. Not following these instructions can affect the heater's performance and safety. Ensure repairs are done by professionals using the correct parts.

## Important Notes

1. Ensure the heater is placed on a flat, hard surface to reduce vibration and noise. Avoid placing the appliance on a soft surface, as it could interfere with its function. Always use the unit on a smooth, stable surface for optimal performance.

2. Place the heater away from open windows, as rain or other natural elements may cause electrical hazards. Keep the appliance free from heavy objects and avoid tipping it on its side to prevent damage. Ensure that no objects are inserted into the unit's body to avoid potential failure.

3. Do not place the heater near heat-generating devices, flammable materials, or dangerous substances. Keep at least one meter of clearance around the unit, especially from furniture, bedding, or other combustibles.

5. Arrange the power cord to prevent tripping hazards. Additionally, avoid placing the heater near animals, curtains, or any flammable objects. Always store the appliance safely after use.

6. Avoid placing the power cord under carpets or furniture, as it may block the tip-over switch.

7. Keep at least 1 meter of space around the heater for optimal airflow and avoid placing it in corners or near obstructions.

**Warning:** Do not place the heater near a hot gas or electric burner.

## Battery Installation Guide

To install the battery, first, remove the battery cover by placing a thumb or small tool on the grooved area and gently pulling it to the side. Insert one CR2025 battery into the compartment, ensuring the positive side faces upwards. Secure the battery cover back into place, ensuring it locks into

position properly. If you suspect that a battery has been swallowed or inserted into any part of the body, seek immediate medical attention. If the battery contents come into contact with the skin, wash the affected area with mild soap and water. In case of eye contact, rinse the eye with water for at least 15 minutes and seek medical assistance. The battery's electrolyte contains organic solvents and lithium salts, which may be harmful.

**Danger:** There is a risk of explosion if the battery is incorrectly replaced. This product contains a coin/button cell battery, which poses a significant chemical burn hazard. If the coin/button cell battery is swallowed, it can cause severe internal burns within just two hours and may lead to death. Extreme caution should be exercised when handling or replacing the battery to avoid ingestion, especially by children.

## Repair or Replacement

**Warning:** For your safety and to ensure the proper functioning of the product, do not attempt to repair, disassemble, puncture, or replace any parts of the heater yourself. Any unauthorized attempts to modify or repair the product will not only compromise its safety but also void the warranty. We strongly recommend that you seek professional assistance from authorized service personnel if the product requires repair or servicing. Always follow the manufacturer's guidelines to maintain the product's warranty coverage and safe operation.



## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
<https://www.greenlion.net/warranty>

## Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: <https://www.greenlion.net/>

Sales: [sales@greenlion.net](mailto:sales@greenlion.net)

Service Support: [Support@greenlion.net](mailto:Support@greenlion.net)

Telegram: [@greenlion\\_global](https://t.me/greenlion_global)

Instagram: [@greenlion\\_global](https://www.instagram.com/greenlion_global)