

PORODO



Porodo

**6 Essentials in 1
ULTIMATE COMBO**

SKU: PDPBFCH071CB

Table of Contents

Product Overview	2
Package Contents	2
Specifications	2
Safety Precautions	4
FCC Statement	6
Disposal	7
Warranty	8
Contact Us	8

Product Overview

The Porodo Ultimate Combo includes six essential accessories designed to enhance your charging experience. It features a 10000mAh power bank and a 20000mAh power bank, providing portable power for your devices on the go. Additionally, it includes a Dual Port GaN Charger and a Dual Port Car Charger, ensuring fast and efficient charging whether at home or on the road. The combo also comes with a 1.2m 4-in-1 Charging Cable, making it compatible with various devices, ensuring convenience and versatility in one complete package. All these accessories are neatly stored in a sleek and functional carry case, perfect for keeping everything organized while traveling or for daily use.

Package Contents

10000 mAh power bank x1
20000 mAh power bank x1
30W Car Charger x1
4-in-1 Aluminum Charging Cable x1
20W Dual Port GaN Charger UK x1
Carrying Case x1

Specifications

a. 10000 mAh Power Bank Specifications

Capacity	10000mAh, 37Wh, 3.7V
Type-C Input	5V/2A, 9V/2A, 12V/1.5A, 18W Max

Type-C Output	5V/3A, 9V/2A, 12V/1.67A, 20W Max
USB-A Output	5V/4.5A, 9V/2A, 12V/1.5V, 22.5W Max

b. 20000 mAh Power Bank Specifications

Capacity	20000mAh, 37Wh, 3.7V
Type-C Input	5V/2A, 9V/2A, 12V/1.5A, 18W Max
Type-C Output	5V/3A, 9V/2A, 12V/1.67A, 20W Max
USB-A Output	5V/4.5A, 9V/2A, 12V/1.5A, 22.5W Max

c. Car Charger Specifications

Input Voltage	12V-24V
USB-A Output	5V/3A, 9V/3A, 12V/2.5A, 30W
USB-C Output	5V/3A, 9V/3A, 12V/2.5A, 30W
Material	PC

d. 4-in-1 Charging Cable Specifications

Input Interface	USB-A & USB-C
-----------------	---------------

Output Interface	Type-C, Lightning
Cable Length	1.2M

e. Dual Port GaN Charger Specifications

Rated Voltage	100-240V
Rated Frequency	50/60Hz
USB-C Output	5V/3A, 9V/2.22A, 12V/1.67A, 20W Max
USB-A Output	5V/3A, 9V/2A, 12V/1.5A, 18W Max

Safety Precautions

1. Dual Port Gan Charger & Car Charger

- a.** Do not cover the charger while charging. Overheating can damage the charger and connected devices.
- b.** Ensure that the wall charger is plugged into a power outlet that matches its voltage rating (110V-240V). Using it with incorrect voltage may cause malfunction or damage.
- c.** Check the charger for any visible damage, such as frayed cables or exposed wires, before use. Do not use any damaged units to avoid electrical hazards.
- d.** Unplug the wall charger or car charger once your device is fully charged to prevent overheating or damaging the battery.
- e.** Ensure that the charger is being used with devices that are compatible with its power output (e.g., voltage and current ratings). Using incompatible

devices may result in overheating or short-circuiting.

f. Avoid using the charger when it's wet or in wet conditions. Water or moisture can cause electrical shorts and pose a risk of shock or fire.

g. Always plug the charger into the power outlet first before connecting it to the device to avoid accidental sparks or power surges.

h. When using the car charger, make sure it is securely plugged into the vehicle's power outlet. Do not leave it plugged in while the vehicle is off, as it may drain the car battery.

j. Do not plug in multiple high-power devices to the same charger at the same time, as this could overload the charger and increase the risk of overheating or damage.

2. Power Banks

a. Always unplug the power bank once it is fully charged. Overcharging can lead to overheating and reduce the lifespan of the battery.

b. Keep your power bank away from direct sunlight, high heat sources, or extremely cold environments. Extreme temperatures can cause the battery to fail or even leak.

c. Do not drop, crush, or subject the power bank to physical shock. Damage to the power bank's casing or internal components can lead to malfunction or pose safety risks.

d. Always use the provided charging cables or high-quality third-party cables to charge the power bank and your devices. Poor-quality or incompatible cables can cause overheating or short-circuiting.

e. Keep the power bank dry and avoid exposing it to water or moisture. Water ingress can cause internal damage, posing a risk of short-circuiting or electrical shock.

f. Ensure the power bank is placed in a well-ventilated area while charging to prevent overheating. Do not cover it with clothes, blankets, or other objects during charging.

g. When not being use, store the power bank in a cool, dry place. Avoid storing it in extreme conditions or areas with high humidity.

h. Do not open or disassemble the power bank. It contains sensitive components,

and tampering with them could lead to leaks, fire hazards, or electrical damage.

j. Regularly inspect the power bank for signs of physical damage, such as swelling, cracks, or exposed areas. If you notice any damage, discontinue use immediately and replace the power bank.

k. Do not allow the power bank's terminals to come into contact with metal objects like keys or coins, as this can cause short-circuiting and potential fire hazards.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference; and

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for assistance.

RF warning statement:

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **<https://www.porodo.net/>**

Service Support: **support@porodo.net**

Instagram: **porodo**